

**INSTALLATION, OPERATION,
AND MAINTENANCE MANUAL**
WITH PARTS LIST



S SERIES PUMPS

MODELS
S6E1—E60 460/3 <i>and</i> S6E1—E60 575/3

GORMAN-RUPP PUMPS

www.grpumps.com

Register your new
Gorman-Rupp pump online at
www.grpumps.com

Valid serial number and e-mail address required.

RECORD YOUR PUMP MODEL AND SERIAL NUMBER

Please record your pump model and serial number in the spaces provided below. Your Gorman-Rupp distributor needs this information when you require parts or service.

Pump Model: _____

Serial Number: _____

TABLE OF CONTENTS

INTRODUCTION	PAGE I – 1
SAFETY - SECTION A	PAGE A – 1
INSTALLATION – SECTION B	PAGE B – 1
GENERAL INFORMATION	PAGE B – 1
Pump Model Designation	PAGE B – 1
PREINSTALLATION INSPECTION	PAGE B – 1
PUMP SEAL	PAGE B – 1
LUBRICATION	PAGE B – 1
PUMP INSTALLATION	PAGE B – 2
Pump Motor Specifications	PAGE B – 2
Pump Dimensions	PAGE B – 10
Lifting	PAGE B – 10
Positioning the Pump	PAGE B – 10
Piping	PAGE B – 11
ELECTRICAL CONNECTIONS	PAGE B – 12
Control Box Installation	PAGE B – 12
Dual Voltage Usage	PAGE B – 12
Field Wiring Connections (Incoming Power)	PAGE B – 13
Grounding Methods	PAGE B – 13
Pump Power Cable Connections	PAGE B – 14
Control Box Specifications	PAGE B – 20
Control Box Connections	PAGE B – 20
Liquid Level Devices	PAGE B – 20
WIRING DIAGRAMS	PAGE B – 21
OPERATION – SECTION C	PAGE C – 1
GENERAL INFORMATION	PAGE C – 1
Pump Performance	PAGE C – 1
Control Box	PAGE C – 1
PUMP OPERATION	PAGE C – 1
Liquid Temperature And Overheating	PAGE C – 1
Impeller Rotation	PAGE C – 2
STARTING, STOPPING AND OPERATIONAL CHECKS	PAGE C – 3
Starting	PAGE C – 3
Stopping	PAGE C – 3
Operational Checks	PAGE C – 3
COLD WEATHER PRESERVATION	PAGE C – 4
LUBRICATION	PAGE C – 4
Draining Oil	PAGE C – 5
Condition of Oil	PAGE C – 5
Adding Oil	PAGE C – 5
TROUBLESHOOTING – SECTION D	PAGE D – 1
ELECTRICAL TESTING	PAGE D – 3
Test Equipment	PAGE D – 3

TABLE OF CONTENTS
(continued)

Voltage Imbalance	PAGE D – 3
Motor And Motor Power Cable Continuity	PAGE D – 3
Insulation Resistance	PAGE D – 4
PREVENTIVE MAINTENANCE	PAGE D – 5
PUMP MAINTENANCE AND REPAIR – SECTION E	PAGE E – 1
PERFORMANCE CURVE	PAGE E – 1
PARTS LISTS	
Pump Models S6E1–E60 460/3 & S6E1–E60 575/3	PAGE E – 3
47367–079 Terminal Housing And Cable Assembly	PAGE E – 5
PUMP AND SEAL DISASSEMBLY AND REASSEMBLY	PAGE E – 6
PUMP END DISASSEMBLY	PAGE E – 6
Strainer Removal	PAGE E – 6
Draining Oil From Seal Cavity	PAGE E – 6
Positioning Pump For Disassembly	PAGE E – 7
Suction Head and Wear Ring Removal	PAGE E – 7
Diffuser Removal	PAGE E – 7
Impeller Removal	PAGE E – 7
Lower Seal Removal	PAGE E – 7
Upper Seal Removal	PAGE E – 8
PUMP END REASSEMBLY	PAGE E – 8
Cleaning And Inspection Of Pump Parts	PAGE E – 8
Upper Seal Installation	PAGE E – 9
Lower Seal Installation	PAGE E – 10
Impeller Installation	PAGE E – 11
Diffuser Installation	PAGE E – 11
Impeller Clearance	PAGE E – 11
Suction Head and Wear Ring Installation	PAGE E – 11
Strainer Installation	PAGE E – 12
MOTOR DISASSEMBLY	PAGE E – 12
Terminal Housing And Power Cable Removal And Disassembly	PAGE E – 12
Shaft And Rotor Disassembly	PAGE E – 13
Bearing Removal	PAGE E – 14
Stator Removal	PAGE E – 14
Hoisting Bail	PAGE E – 15
MOTOR REASSEMBLY	PAGE E – 15
Stator Installation	PAGE E – 15
Bearing Installation	PAGE E – 16
Rotor and Lower Motor Housing Reassembly	PAGE E – 17
Rotor and Lower Motor Housing Installation	PAGE E – 18
Motor Housing Reassembly	PAGE E – 18
Terminal Housing And Power Cable Reassembly And Installation	PAGE E – 18
Sealing Terminal Housing Connections With Silicone Adhesive	PAGE E – 19
Sealing Terminal Housing Connections With Potting Compound	PAGE E – 21
Terminal Housing Installation	PAGE E – 22
FINAL ASSEMBLY	PAGE E – 22
VACUUM TESTING	PAGE E – 22
LUBRICATION	PAGE E – 23
Seal Cavity	PAGE E – 23
Motor Housing Cavity	PAGE E – 24

INTRODUCTION

Thank You for purchasing a Gorman-Rupp pump. **Read this manual** carefully to learn how to safely install and operate your pump. Failure to do so could result in personal injury or damage to the pump.

This Installation, Operation, and Maintenance manual is designed to help you achieve the best performance and longest life from your Gorman-Rupp pump.

The pump is specifically designed for mine dewatering applications. It is capable of handling most non-volatile, non-flammable liquids encountered in standard mining operations. Refer to the following chart for the materials of construction for your particular pump. The pump may be operated fully or partially submerged, since the integral air-filled electric motor is thermally protected and cooled by the liquid being pumped. The motor must be operated through the control box furnished with the pump as standard equipment. The pump and control comply with MSHA schedule 2G regulations.

The basic material of construction is aluminum, with G-R hard iron impeller, diffuser and seal plate.

Because pump installations are seldom identical, this manual cannot possibly provide detailed instructions and precautions for every aspect of each specific application. Therefore, it is the responsibility of the owner/installer of the pump to ensure that applications not addressed in this manual are performed **only** after establishing that neither operator safety nor pump integrity are compromised by the installation. Pumps and related equipment **must** be installed and operated according to all national, local and industry standards.

If there are any questions regarding the pump or its application which are not covered in this manual or in other literature accompanying this unit, please contact your Gorman-Rupp distributor, or write:

The Gorman-Rupp Company
P.O. Box 1217
Mansfield, Ohio 44901-1217
Phone: (419) 755-1011

or:

Gorman-Rupp of Canada Limited
70 Burwell Road
St. Thomas, Ontario N5P 3R7
Phone: (519) 631-2870

The following are used to alert maintenance personnel to procedures which require special attention, to those which could damage equipment, and to those which could be dangerous to personnel:



Immediate hazards which WILL result in severe personal injury or death. These instructions describe the procedure required and the injury which will result from failure to follow the procedure.



Hazards or unsafe practices which COULD result in severe personal injury or death. These instructions describe the procedure required and the injury which could result from failure to follow the procedure.



Hazards or unsafe practices which COULD result in minor personal injury or product or property damage. These instructions describe the requirements and the possible damage which could result from failure to follow the procedure.

NOTE

Instructions to aid in installation, operation, and maintenance or which clarify a procedure.

SAFETY – SECTION A

This information applies to the S Series submersible motor driven pumps and control boxes.

Because pump installations are seldom identical, this manual cannot possibly provide detailed instructions and precautions for each specific application. Therefore, it is the owner/installer's responsibility to ensure that applications not addressed in this manual are performed only after establishing that neither operator safety nor pump integrity are compromised by the installation.



Before attempting to open or service the pump:

1. Familiarize yourself with this manual.
2. Lock out incoming power to the control box to ensure that the pump will remain inoperative.
3. Allow the pump to completely cool if overheated.
5. Close the discharge valve (if used).



This pump is not designed to pump volatile, explosive, or flammable materials. Do not attempt to pump any liquids for which you pump is not approved, or which may damage the pump or endanger personnel as a result of pump failure. Consult the factory for specific application data.



Before connecting any cable to the control box, be sure to ground the control box. Refer to the Control Box Manual for the suggested grounding methods.



The pump motor is designed to be operated through the control box furnished with the pump. The control box provides overload protection and power control. Do not connect the pump motor directly to the incoming power lines.



The electrical power used to operate this pump is high enough to cause injury or death. Obtain the services of a qualified electrician to make all electrical connections. Make certain that the pump and enclosure are properly grounded; never use gas pipe as an electrical ground. Be sure that the incoming power matches the voltage and phase of the pump and control before connecting the power source. Do not run the pump if the voltage is not within the limits. If the overload unit is tripped during pump operation, correct the problem before restarting the pump.



The electrical power used to operate this pump is high enough to cause injury or death. Make certain that the control handle on the control box is in the OFF

position and locked out, or that the power supply to the control box has been otherwise cut off and locked out, before attempting to open or service the pump assembly. Tag electrical circuits to prevent accidental start-up.



Never attempt to alter the length or repair any power cable with a splice. The pump motor and cable must be completely waterproof. Injury or death may result from alterations.



All electrical connections must be in accordance with The National Electric Code and all local codes. If there is a conflict between the instructions provided and N.E.C. Specifications, N.E.C. Specifications shall take precedence. All electrical equipment supplied with this pump was in conformance with N.E.C. requirements in effect on the date of manufacture. Failure to follow applicable specifications, or substitution of electrical parts not supplied or approved by the manufacturer, can result in severe injury or death and void warranty.



Death or serious personal injury and damage to the pump or components can occur if proper lifting procedures are not observed. Make certain that hoists, chains, slings or cables are in good working condition and of sufficient capacity and that they are positioned so that loads will be balanced

and the pump or components will not be damaged when lifting. Do not attempt to lift this pump by the motor or control cables, or the piping. Attach proper lifting equipment to the lifting bail fitted on the pump. Lift the pump or component only as high as necessary and keep personnel away from suspended objects.



After the pump has been installed, make certain that the pump and all piping or hose connections are secure before operation.



Obtain the services of a qualified electrician to troubleshoot, test and/or service the electrical components of this pump.



Approach the pump cautiously after it has been running. Although the motor is cooled by the liquid being pumped, normal operating temperatures can be high enough to cause burns. The temperature will be especially high if operated against a closed discharge valve. Never operate against a closed discharge valve for long periods of time.




Do not remove plates, covers, gauges, pipe plugs, or fittings from an overheated pump. Vapor pressure within the pump can cause parts being disengaged to be ejected with great force. Al-

low the pump to completely cool before servicing.



Do not attempt to lift the pump by the motor power cable or the piping. Attach proper lifting equipment to the lifting device fitted to the pump. If chains or cable are wrapped around the pump to

lift it, make certain that they are positioned so as not to damage the pump, and so that the load will be balanced.



Pumps and related equipment must be installed and operated according to all national, local and industry standards.

INSTALLATION – SECTION B

GENERAL INFORMATION

Review all SAFETY information in Section A.

Since pump installations are seldom identical, this section is intended only to summarize general recommendations and practices required to inspect, position, and arrange the pump and piping. If there are any questions concerning your specific installation, contact your Gorman-Rupp distributor or the Gorman-Rupp Company.

Liquid level devices are available from Gorman-Rupp as optional equipment. For information on installing and operating these items, refer to the literature accompanying them.

Pump Model Designation

Following is a description of the model numbering system for S Series pumps. These submersible pumps are available in a range of sizes. Refer to the following chart to identify the size for your specific pump model.

Pump Model						
S	3	C	1	–	E 6.2	230/3
Series	Discharge Size	Pump Hydraulics	Pump Construction		H.P. (If Shown)	Voltage/Phase

PREINSTALLATION INSPECTION

The pump assembly was inspected and tested before shipment from the factory. Before installation, check for damage which may have occurred during shipment. Check as follows:

- Inspect the pump assembly for cracks, dents, damaged threads, and other obvious damage.
- Check for loose attaching hardware. Since gaskets tend to shrink after drying, check for loose hardware at the mating surfaces.
- Inspect the power cable for cuts or any other obvious damage.
- Check that amperes, phase, voltage and hertz indicated on the name plate match the

ratings on the control box and incoming power.

- Carefully read all tags, decals, and markings on the pump, and perform all duties indicated.
- Check for oil leaks. If there is any indication of an oil leak, see **LUBRICATION** at the end of this manual.

PUMP SEAL

S Series pumps utilize one of the following sealing methods.

- There are two shaft seals in the pump. The lower seal prevents liquid from entering the intermediate cavity at the impeller end. The upper seal prevents oil leakage from the motor housing cavity and acts as back-up protection in the event of lower seal failure.
- The pump is equipped with one double-faced seal assembly. It is designed to prevent the liquid being pumped from entering the intermediate cavity at the impeller end, and to prevent moisture from entering the motor housing cavity at the motor end.

Regardless of which sealing method is used, the seal is lubricated by premium quality submersible pump oil.

LUBRICATION

S series pumps are lubricated in one of the following methods.

- Some pumps utilize two lubrication cavities. The motor housing cavity provides lubrication to the motor assembly and bearings, while the intermediate cavity provides lubrication to the pump seal.
- Some pumps utilize one lubrication cavity, located just behind the seal plate. It is filled with premium quality submersible pump oil which lubricates the pump seal. The motor operates in and is cooled by air, therefore it requires no lubrication.

All S Series pumps are fully lubricated when shipped from the factory. However, lubrication levels **must be checked** before installing the pump

(see **LUBRICATION** in the **MAINTENANCE AND REPAIR MANUAL**). An additional quart (0,9 liter) of oil is provided to “top off” the oil level in the pump motor cavity, if so required. If the oil level is abnormally low, determine the cause before putting the pump into service.

Due to differences in pump design, the quantity of oil and manner in which oil is to be added to the seal cavity varies between pump models. Refer to

Table B-2 for oil capacities and positions for filling the seal cavity in each pump. Motor cavities requiring lubrication should always be positioned vertically for filling. Refer to **LUBRICATION**, Section C for lubrication specifications and intervals.

PUMP INSTALLATION

Pump Motor Specifications

See Table B-1 for pump specifications.

Table B-1. Pump Specifications

Model	Voltage/ Phase	Dual Voltage	Pump HP/ KW	Motor Speed (RPM)	Full Load Amperes	No Load Amperes	Locked Rotor Amperes	Discharge Size (NPT)
S2A	115/1	NO	2 HP	3450	28	14	82	2 INCH
	230/1				14	7	44	
S2B	115/1	NO	2 HP	3450	28	9	85	2 INCH
	230/1	YES			12	4.2	38	
	200/3	NO			8.3	4.6	57.5	
	230/3	YES	7.2	4	50			
	460/3		3.6	2	25			
	575/3	NO	2.9	1.6	20			
380/3	NO	1.4 KW	2900	2.5	2	25		
S2E	200/3	NO	3.5 HP	3450	10.4	1.8	23	2 INCH
	230/3	YES			9.0	4	50	
	460/3				4.5	2	25	
	575/3	NO	3.6	1.6	20			
	380/3	NO	1.4 KW	2900	3.8	2	25	
S2F	115/1	YES	1 HP	3450	15	9.7	54	2 INCH
	230/1				7.5	4.9	36	
	200/3	NO			5	3.7	24	
	230/3	YES	4.3	3.2	21			
	460/3		2.2	1.6	10.5			
	575/3	NO	1.8	1.3	8.4			
	110/1	YES	1.1 KW	2900	12	9.8	54	
	220/1				6	5.6	36	
	380/3	NO			1.8	1.5	10.5	
S3A	230/1	NO	5 HP	3450	28	5	125	2 INCH
	200/3	NO			18	9	75	

Table B-1. Pump Specifications (continued)

Model	Voltage/ Phase	Dual Voltage	Pump HP/ KW	Motor Speed (RPM)	Full Load Amperes	No Load Amperes	Locked Rotor Amperes	Discharge Size (NPT)
S3A	230/3	YES	5 HP	3450	16	8	65	3 INCH
	460/3				8	4	35	
	575/3	NO	3 KW	2900	6.5	3.2	28	
	380/3	NO			5.4	3.5	35	
S3B	230/1	NO	6 HP	3450	34	8	95	3 INCH
	200/3	NO			26.5	13.8	115	
	230/3	YES			23	12	100	
	460/3		11.5	6	50			
	575/3	NO	9.2	4.8	40			
	380/3	NO	4 KW	2900	12.4	6	50	
S3C	230/1	NO	6 HP	3450	34	8	95	3 INCH
	200/3	NO			26.5	13.8	115	
	230/3	YES			23	12	100	
	460/3		11.5	6	50			
	575/3	NO	9.2	4.8	40			
	380/3	NO	4 KW	2900	8	6	50	
S3D	230/1	NO	5 HP	3450	28	5	125	3 INCH
	200/3	NO			18	9	75	
	230/3	YES			16	8	65	
	460/3		8	4	35			
	575/3	NO	6.5	3.2	28			
	380/3	NO	3 KW	2900	5.4	4	35	
S4A	230/3	NO	25 HP	1750	160	10	204	4 INCH
	460/3				30	5	102	
	575/3		12 KW	1450	24	4	82	
	380/3				21	5	102	
S4B	230/3	NO	50 HP	1750	124	30	400	4 INCH
	460/3				62	15	200	
	575/3		25 KW	1450	50	12	160	
	380/3				46	11	137	
S4C	200/3	NO	10 HP	3450	39	8	170	4 INCH
	230/3	YES			34	7	148	

Table B-1. Pump Specifications (continued)

Model	Voltage/ Phase	Dual Voltage	Pump HP/ KW	Motor Speed (RPM)	Full Load Amperes	No Load Amperes	Locked Rotor Amperes	Discharge Size (NPT)
S4C	460/3	YES	10 HP	3450	17	3.5	74	4 INCH
	575/3	NO			13.6	2.8	60	
	380/3	NO	6.7 KW	2900	11.5	3.5	74	
S4D	200/3	NO	10 HP	3450	39	8	170	4 INCH
	230/3	YES			34	7	148	
	460/3				17	3.5	74	
	575/3	NO	6.7 KW	2900	13.6	2.8	60	
	380/3	NO			11.5	3.5	74	
S4E	460/3	NO	20 HP	3450	26	4.4	170	4 INCH
	575/3				20.8	3.5	136	
S4F	460/3	NO	20 HP	3450	26	4.4	170	4 INCH
	575/3				20.8	3.5	136	
S4G	460/3	NO	30 HP	3450	38.5	7.5	213	4 INCH
	575/3				30.8	6	170	
S4H	200/3	NO	10 HP	3450	39	8	276	4 INCH
	230/3	YES			34	7	240	
	460/3				17	3.5	120	
	575/3	NO	6.7 KW	2900	13.6	2.8	96	
	380/3	YES			11.5	3.5	145	
S4J	460/3	NO	60 HP	3450	66	11	500	4 INCH
	575/3				52.8	8.8	400	
S4K	460/3	NO	15 HP	3450	17	3.5	100	4 INCH
	575/3				13.6	2.8	80	
S6A	230/3	NO	60 HP	1750	130	30	574	6 INCH
	460/3				65	15	287	
	575/3		26 KW	1450	52	12	230	
	380/3				47	12	200	
S6B	230/3	NO	95 HP	1750	210	70	930	6 INCH
	460/3				105	35	465	
	575/3				84	28	372	
	380/3		41 KW	1450	76	20	287	
	500/3				58	15	264	

Table B-1. Pump Specifications (continued)

Model	Voltage/ Phase	Dual Voltage	Pump HP/ KW	Motor Speed (RPM)	Full Load Amperes	No Load Amperes	Locked Rotor Amperes	Discharge Size (NPT)
S6C	230/3	NO	35 HP	1750	80	14	274	6 INCH
	460/3				40	7	137	
	575/3		15 KW	1450	32	5.5	110	
	380/3				28	6	102	
S6D	460/3	NO	30 HP	3450	38.5	7.5	213	6 INCH
	575/3				30.8	6	170	
S6E	460/3	NO	60 HP	3450	66	11	500	6 INCH
	575/3				52.8	8.8	400	
S8A	230/3	NO	95 HP	1750	210	70	930	8 INCH
	460/3				105	35	465	
	575/3		44 KW	1450	84	28	372	
	380/3				82	20	287	
S8B	460/3	NO	100 HP	1750	125	35	465	8 INCH
	575/3				100	28	372	
	380/3		51 KW	1450	96	20	287	
S8C	460/3	NO	140 HP	1750	165	50	697	8 INCH
	575/3				132	40	558	
	380/3		65 KW	1450	115	24	465	
S8D	460/3	NO	275 HP	1750	353	69	1750	8 INCH
	575/3				282	55	1400	
S12A	460/3	NO	140 HP	1750	160	50	697	12 INCH
	575/3				128	40	558	

Table B-2. Additional Specifications

Pump Model	Voltage/Phase	Approximate Weight – Lbs. (kg)		Oil Capacity Ounces (Liters)		Seal Cavity Filling Position (H)orizontal (V)ertical *(A)ngle
		Pump	50 Ft. Cable	Seal Cavity	Motor Cavity	
S2A	115/1	62 (28)	18 (8)	8 (0,2)	32 (1)	A
	230/1	57 (26)	12 (5)			
S2B	115/1	56 (25)	18 (8)	8 (0,2)	32 (1)	V
	230/1		12 (5)			
	200/3					
	230/3					
	460/3					
	575/3					
	380/3					
S2E	200/3	73 (33)	12 (5)	8 (0,2)	32 (1)	V
	230/3					
	460/3					
	575/3					
	380/3					
S2F	115/1	44 (20)	12 (5)	8 (0,2)	32 (1)	V
	230/1					
	200/3					
	230/3					
	460/3					
	575/3					
	110/1					
	220/1					
	380/3					
S3A	230/1	55 (25)	18 (8)	24 (0,6)	32 (1)	A
	200/3				56 (1,7)	
	230/3					
	460/3					
	575/3					
	380/3					

* Position Pumps at Approximately 30° off Vertical

Table B-2. Additional Specifications (continued)

Pump Model	Voltage/ Phase	Approximate Weight – Lbs. (kg)		Oil Capacity Ounces (Liters)		Seal Cavity Filling Position (H)orizontal (V)ertical *(A)ngle
		Pump	50 Ft. Cable	Seal Cavity	Motor Cavity	
S3B	230/1	77 (35)	18 (8)	16 (0,5)	80 (2,4)	H
	200/3				96 (2,8)	
	230/3					
	460/3					
	575/3					
	380/3					
S3C	230/1	102 (46)	18 (8)	16 (0,5)	80 (2,4)	H
	200/3				96 (2,8)	
	230/3					
	460/3					
	575/3					
	380/3					
S3D	230/1	102 (46)	18 (8)	24 (0,7)	32 (1)	H
	200/3				56 (1,7)	
	230/3					
	460/3					
	575/3					
	380/3					
S4A	230/3	423 (192)	43 (20)	96 (2,8)	352 (10,4)	V
	460/3					
	575/3					
	380/3					
S4B	230/3	741 (336)	80 (36)	160 (4,7)	256 (7,6)	V
	460/3		43 (20)			
	575/3					
	380/3					

* Position Pumps at Approximately 30° off Vertical

Table B-2. Additional Specifications (continued)

Pump Model	Voltage/ Phase	Approximate Weight – Lbs. (kg)		Oil Capacity Ounces (Liters)		Seal Cavity Filling Position (H)orizontal (V)ertical *(A)ngle
		Pump	50 Ft. Cable	Seal Cavity	Motor Cavity	
S4C	200/3	173 (78)	33 (15)	20 (0,6)	96 (2,8)	H
	230/3					
	460/3					
	575/3					
	380/3					
S4D	200/3	167 (76)	33 (15)	20 (0,6)	96 (2,8)	H
	230/3					
	460/3					
	575/3					
	380/3					
S4E	460/3	302 (137)	38 (17)	32 (1)	---	H
	575/3					
S4F	460/3	339 (154)	38 (17)	32 (1)	---	H
	575/3					
S4G	460/3	588 (267)	38 (17)	112 (3,3)	---	V
	575/3					
S4H	200/3	167 (76)	33 (15)	20 (0,6)	96 (2,8)	H
	230/3					
	460/3					
	575/3					
	380/3					
S4J	460/3	666 (302)	53 (24)	144 (4,3)	---	V
	575/3					
S4K	460/3	248 (113)	38 (17)	32 (1)	---	H
	575/3					
S6A	230/3	705 (320)	80 (36)	176 (5,2)	832 (24,6)	V
	460/3	743 (337)	43 (20)			
	575/3					
	380/3			160 (4,7)	256 (7,6)	

* Position Pumps at Approximately 30° off Vertical

Table B-2. Additional Specifications (continued)

Pump Model	Voltage/ Phase	Approximate Weight – Lbs. (kg)		Oil Capacity Ounces (Liters)		Seal Cavity Filling Position (H)orizontal (V)ertical *(A)ngle
		Pump	50 Ft. Cable	Seal Cavity	Motor Cavity	
S6B	230/3	865 (392)	150 (68)	176 (5,2)	576 (17)	V
	460/3		69 (31)			
	575/3					
	380/3					
	500/3		43 (20)			
S6C	230/3	435 (197)	80 (36)	96 (2,8)	288 (8,5)	V
	460/3	473 (214)	43 (20)			
	575/3					
	380/3					
S6D	460/3	538 (244)	33 (15)	112 (3,3)	---	V
	575/3					
S6E	460/3	765 (347)	53 (24)	144 (4,3)	---	V
	575/3					
S8A	230/3	870 (395)	150 (68)	176 (5,2)	576 (17)	V
	460/3		80 (36)			
	575/3					
	380/3					
S8B	460/3	1175 (533)	105 (48)	224 (6,6)	768 (22,7)	V
	575/3		80 (36)		864 (25,6)	
	380/3					
S8C	460/3	1210 (549)	150 (68)	208 (6,2)	576 (17)	V
	575/3	1255 (569)			768 (22,7)	
	380/3					
S8D	460/3	3462 (1570)	150 (68) each, 2 cables required	461 (13,6)	1709 (50,5)	V
	575/3					
S12A	460/3	1441 (654)	150 (68)	102 (3)	592 (17,5)	V
	575/3		105 (48)			

* Position Pumps at Approximately 30° off Vertical

Pump Dimensions

For the approximate physical dimensions of your pump, refer to the pump specification data sheet or contact your Gorman-Rupp distributor or the Gorman-Rupp Company.



When installing or servicing the pump or controls, follow all requirements for the installation of wiring or electrical equipment as outlined in the National Electric Code. Follow all safety requirements. Failure to observe these requirements could result in injury or death to personnel.



Do not allow the free end of the power cable to enter the liquid being pumped. The free end of the cable **must** be kept dry to prevent liquid from wicking through the cable and into the motor.

NOTE

*Refer to the performance curve in the Parts List Manual when determining the most efficient piping installation. **The recommended maximum submergence depth is 65 feet.***

Lifting

Pump unit weights will vary depending on the mounting and drive provided. Check the shipping tag on the unit packaging for the actual weight, and use lifting equipment with appropriate capacity. Drain the pump and remove all customer-installed equipment such as suction and discharge hoses or piping before attempting to lift existing, installed units.

Refer to Table B-2 for the approximate maximum weight for each pump.



Death or serious personal injury and damage to the pump or components can occur if proper lifting procedures are not observed. Make certain that hoists, chains, slings or cables are in good working condition and of sufficient capacity and that they are positioned so that loads will be balanced and the pump or components will not be damaged when lifting. Do not attempt to lift this pump by the motor or control cables, or the piping. Attach proper lifting equipment to the lifting bail fitted on the pump. Lift the pump or component only as high as necessary and keep personnel away from suspended objects.



Use **Only Genuine Gorman-Rupp** replacement parts. Failure to do so may create a hazard and damage the pump or diminish optimal pump performance. Any such hazard, damage or diminished performance is not covered by the warranty.

NOTE

When appropriate recycling facilities are available, the user should recycle components and fluids when doing any routine maintenance / repairs and also at the end of the pump's useful life. All other components and fluids shall be disposed of according to all applicable codes and regulations.

Positioning the Pump

NOTE

*Before installing and operating the pump, check the direction of impeller rotation to ensure that the pump is properly wired at the control box. See **IMPELLER ROTATION**, Section C.*

The pump is designed to operate fully or partially submerged. The rotating parts are oil lubricated, and the motor is cooled by a constant flow of liquid or air discharged through internal passages.

As a safeguard against rupture or explosion due to heat, models equipped with oil-lubricated motors are fitted with a pressure relief valve which will open if vapor pressure within the pump motor reaches a critical point.

The pump will operate if positioned on its side, but this is not recommended because the motor torque could cause the pump to roll during opera-

tion.

The pump should be independently secured and supported by the lifting device fitted on the pump. If the application involves a lot of debris, protect the pump from excessive wear and clogging by suspending it in a perforated barrel or culvert pipe. If the bottom is heavily sludge-covered, rest the pump on support blocks or suspend it from a raft or similar device near the surface of the liquid. See Figure B-1 for typical pump installations.

All liquid entering the pump must pass through a strainer screen. Any spherical solids which pass through the screen will pass through the pump.




Figure B-1 Typical Pump Installations

Piping

No suction piping is required in a standard installation.

S Series pumps are provided with a suction strainer to prevent large solids from clogging the impeller. On some models the strainer can be removed and the pump suction “staged” to the discharge of another pump, allowing one pump to feed the other on high discharge head applications.

To determine the size of the discharge connection, see **Table B-1, Pump Specifications**. Either

hose or rigid pipe may be used. To facilitate mobility and maintenance, it is recommended that the discharge line be fitted with a quick disconnect fitting near the pump. The discharge line must be independently supported to avoid strain and vibration on the pump.

Either hose or rigid pipe may be used to make discharge connections. For maximum pumping capacity, keep the line as short and straight as possible. Elbows and fittings used in discharge lines increase friction loss, minimize their use.

It is recommended that a check valve or throttling valve be installed in the discharge line to control siphoning or back flow when the pump is shut off.

ELECTRICAL CONNECTIONS



Install and operate this pump in accordance with the National Electrical Code and all local codes. Have a qualified electrician perform all checks and connections in this section.

Never attempt to alter the length of the pump motor cable or to repair it with a splice. The power cable and pump motor must be kept completely waterproof. Serious damage to the pump and injury or death to personnel can result from any alteration to the cable.

Control Box Installation



The pump is designed to be operated through the control box furnished with the pump. The control box provides overload protection and power control. Do not connect the pump motor directly to the incoming power lines.

The control box is a rainproof enclosure with a padlockable front cover. **The enclosure is not designed to be watertight, and should not be submerged.** Refer to the control box manual for enclosure dimensions and parts.

Secure the control vertically on a level surface, above flood level. The box should be easily accessible to the operator, and located close enough to the pump to avoid excessive voltage drop due to cable length (see **Pump Power Cable Connection**). After the box is installed, make certain the front cover latches properly.



Failure to mount the control box vertically on a level surface may affect operation of the pump controls.

Dual Voltage Usage

Some pumps are powered by a dual-voltage motor for utilization with high or low voltage. The motor was originally wired and shipped from the factory for use with the voltage indicated as “Factory Wired” on the pump’s name plate. The name plate also indicates the dual voltage pertaining to this motor. If the alternate voltage must be utilized, control box modifications and/or certain wiring changes are required.


The control box assembly provided with this pump has been designed to accommodate **only** the voltage indicated on the front of the box. This voltage coincides with the “Factory Wired” voltage of the motor. If the alternate voltage is utilized, the control box must be replaced with another box designed for the appropriate voltage. Alternate voltage control boxes are shown in the Parts List Manual under Pump Options.



Dual voltage pumps are wired at the factory only for the voltage shown on the name plate. Make certain that the control box voltage matches the pump voltage before using. If the pump voltage is changed, the pump name plate must be changed and a new control box must be installed. Do not run the pump if the voltages do not match; otherwise, the pump warranty will be negated, and damage to the pump, and injury or death to personnel can result.

The motor wiring **must also** be changed before utilizing alternate voltage. For detailed instructions on disassembly and reassembly of the terminal housing, see **Terminal Housing and Power Cable Disassembly** and **Terminal Housing and Power**

Cable Reassembly in the Maintenance And Repair manual. Change the motor leads as indicated on the wiring diagram plate affixed to the side of the terminal housing (see Figure B-2). **Be sure** to tag the revised voltage on the pump.



Field Wiring Connections (Incoming Power)



The electrical power used to operate this pump is high enough to cause injury or death. Obtain the services of a qualified electrician to make all electrical connections. Make certain that the pump and enclosure are properly grounded; **never** use gas pipe as an electrical ground. Be sure that the incoming power matches the voltage and phase of the pump and control before connecting the power source. Do not run the pump if the voltage is not within the limits.



Do not connect the pump motor directly to the incoming power lines. The pump motor is designed to operate through a Gorman-Rupp approved control box which provides overload protection and power control; otherwise, the pump warranty will be voided. Make certain that the pump and control box are properly grounded. Install and operate the control box in accordance with the Na-

tional Electric Code and all local codes. Failure to follow these could result in injury or death to personnel.

Field wiring is **not** provided with the pump, and must be supplied by the user. The field wiring must be of the proper size and type to ensure an adequate voltage supply to the pump. Voltage available **at the motor** must be within the range indicated in Table B-3.

To calculate the voltage available at the motor, proceed as follows:

- a. Measure the voltage across the incoming lines (1 & 2 for single phase, 1 & 2, 2 & 3, and 1 & 3 for three phase) **while the pump is operating at full capacity**. Refer to the literature supplied with the control box for power supply connections.
- b. Next, subtract the motor cable voltage drop (see Table 4, **Pump Power Cable Specifications**).
- c. Do not continue to operate the pump if this voltage is not within the recommended limits. Obtain the services of a qualified electrician to determine the correct field wiring size and other details to ensure an adequate voltage supply to the pump.

Table B-3. Pump Voltage Requirements

NOMINAL VOLTAGE	PHASE	MINIMUM VOLTAGE	MAXIMUM VOLTAGE
115	1	110	120
230	1	220	240
230	3	210	250
460	3	420	500
575	3	520	630
380	3	345	415

Make certain all connections are tight and that cable entry points are rainproof. Support the cable weight, if required, to prevent excessive strain on cable clamps and cable.

Grounding Methods

Electrically ground the installation before connecting the field wiring to the control box. Install a

grounding terminal to the enclosure and connect it to a properly embedded electrode.

The material used for the electrode **must** be an excellent conductor of electricity, such as copper. If iron or steel is used, it must be galvanized or otherwise metal plated to resist corrosion. **Do not** coat

the electrode with any material of poor conductivity, such as paint or plastic.

The electrode must conform to the recommendations of N.E.C. ARTICLE 250. Follow all installation requirements of the N.E.C., and all applicable codes. See Figure B-3 for some suggested grounding methods.




Figure B-3. Suggested Grounding Methods

- Plate Electrode:** An iron or steel plate, 1/4 inch (6,4 mm) thick, completely impeded in the ground. The plate must present a surface area of at least 2 square feet (1858,1 sq. cm.).
- Driven Electrode:** A rod or pipe, 3/4 inch (19,1 mm) in diameter minimum, 8 feet (2,4 m) long, completely driven into the ground.
- Buried electrode:** If rock or stone prevents embedding the full 8 foot (2,4 m) length of the ground rod, bury it horizontally in a trench.

Space the ground rod or plates at least 6 feet (1,8) from any other electrode or ground rod, such as those used for signal circuits, radio grounds, lightning rods, etc.

The earth surrounding the ground rod or plate **must** contain enough moisture to make a good electrical connection. In dry or sandy areas, pour water around the rod, or consult qualified personnel to devise a method of improving the connections.



The electrical power used to operate this pump is high enough to cause injury or death. Make certain that the control box is properly grounded after installation.

Refer to the literature accompanying the control box for field wiring connections.

Pump Power Cable Connections



The electrical power used to operate this pump is high enough to cause injury or death. Obtain the services of a qualified electrician to make all electrical connections. **Make certain** that incoming power to the control box is **in the OFF position and locked out**, or that the power supply to the control box has

been otherwise **cut off and locked out**, before connecting power or accessory cables.

The pump is provided with a 50 ft. (15,2 m) power cable (see Table B-4 for standard power cable specifications). If a longer cable is required, an optional cable assembly **must** be ordered from the factory. Splicing of the power cable is **not** recommended by the Gorman-Rupp Company due to

safety and warranty considerations.



Never attempt to alter the length or repair any power cable with a splice. The pump motor and cable must be completely waterproof. Injury or death may result from alternations.

Table B-4. Pump Power Cable Specifications

Pump Model	Voltage/Phase	A.W.G Cable Size	Cable O.D. Inches (mm)	Conductor Dia. Inches (mm)	Amp Rating (See Note Below)	Cable Type	DC Resistance (ohms) at 225°C (77°F) per 1000 ft. (305 m)	Voltage Drop per 100 ft. (30,5m) at Max. Load
S2A	115/1	10	0.75 (19)	0.12 (3)	25*	◆ SO	1.11	6.22
	230/1	14	0.61 (16)	0.075(2)	15*		2.73	7.64
S2B	115/1	14	0.61 (16)	0.075(2)	15*	◆ SO	2.73	6.22
	230/1							6.55
	200/3							4.53
	230/3							3.93
	460/3							1.96
	575/3							1.58
	380/3							1.37
S2E	200/3	14	0.61 (16)	0.075(2)	15*	◆ SO	2.73	6.80
	230/3							5.90
	460/3							2.95
	575/3							2.35
	380/3							2.07
S2F	115/1	14	0.61 (16)	0.075(2)	15*	◆ SO	2.73	8.19
	230/1							4.10
	200/3							2.73
	230/3							2.36
	460/3							1.20
	575/3							0.98
	110/1							6.44
	220/1							3.28
	380/3							0.98
S3A	230/1	10	0.75 (19)	0.12 (3)	25*	◆ SO	1.11	6.22
	200/3							4.00
	230/3							3.55
	460/3							1.78
	575/3							1.44
	380/3							1.20

NOTE: * Amp Rating at 30°C (86°F) ◆ Canada Use Type SOW Cable
 ** Amp Rating at 40°C (104°F)

Table B-4. Pump Power Cable Specifications (Continued)

Pump Model	Voltage/Phase	A.W.G Cable Size	Cable O.D. Inches (mm)	Conductor Dia. Inches (mm)	Amp Rating (See Note Below)	Cable Type	DC Resistance (ohms) at 225°C (77°F) per 1000 ft. (305 m)	Voltage Drop per 100 ft. (30,5m) at Max. Load
S3B	230/1	10	0.75 (19)	0.12 (3)	25*	◆ SO	1.11	7.55
	200/3							5.88
	230/3							5.10
	460/3							2.55
	575/3							2.04
	380/3							1.78
S3C	230/1	10	0.75 (19)	0.12 (3)	25*	◆ SO	1.11	7.55
	200/3							5.88
	230/3							5.10
	460/3							2.55
	575/3							2.04
	380/3							1.78
S3D	230/1	10	0.75 (19)	0.12 (3)	25*	◆ SO	1.11	6.22
	200/3							4.00
	230/3							3.55
	460/3							1.78
	575/3							1.44
	380/3							1.20
S4A	230/3	6	1.01 (26)	0.21 (5)	79**	GGC	0.45	5.40
	460/3							2.70
	575/3							2.16
	380/3							1.89
S4B	230/3	2	1.34 (34)	0.34 (9)	138**	GGC	0.17	4.22
	460/3	6	1.01 (26)	0.21 (3)	79**		0.45	5.58
	575/3						4.50	
	380/3						1.05 (27)	4.14
S4C	200/3	8	0.97 (25)	0.17 (4)	59**	GGC	0.71	4.80
	230/3							4.85
	460/3							2.42
	575/3	10	0.75 (19)	0.12 (3)	25*	◆ SO	1.11	3.20

NOTE: * Amp Rating at 30°C (86°F) ◆ Canada Use Type SOW Cable
 ** Amp Rating at 40°C (104°F)

Table B-4. Pump Power Cable Specifications (Continued)

Pump Model	Voltage/Phase	A.W.G Cable Size	Cable O.D. Inches (mm)	Conductor Dia. Inches (mm)	Amp Rating (See Note Below)	Cable Type	DC Resistance (ohms) at 225°C (77°F) per 1000 ft. (305 m)	Voltage Drop per 100 ft. (30,5m) at Max. Load
S4C	380/3	8	0.97 (25)	0.17 (4)	59**	GGC	0.71	2.04
S4D	200/3	8	0.97 (25)	0.17 (4)	59**	GGC	0.71	4.80
	230/3							4.85
	460/3							2.42
	575/3	10	0.75 (19)	0.12 (3)	25*	◆ SO	1.11	3.02
	380/3	8	0.97 (25)	0.17 (4)	59**	GGC	0.71	1.63
S4E	460/3	8	1.05 (27)	0.17 (4)	59**	SPC	0.71	3.69
	575/3							2.95
S4F	460/3	8	1.05 (27)	0.17 (4)	59**	SPC	0.71	3.69
	575/3							2.95
S4G	460/3	8	1.05 (27)	0.17 (4)	59**	SPC	0.71	5.47
	575/3							4.37
S4H	200/3	8	0.97 (25)	0.17 (4)	59**	GGC	0.71	4.80
	230/3							4.85
	460/3							2.42
	575/3	10	0.75 (19)	0.12 (3)	25*	◆ SO	1.11	3.02
	380/3	8	0.97 (25)	0.17 (4)	59**	GGC	0.71	1.63
S4J	460/3	6	1.25 (32)	0.21 (5)	79**	SPC	0.45	5.94
	575/3							4.75
S4K	460/3	12	.89 (23)	0.10 (3)	30*	SPC	1.72	5.85
	575/3							4.68
S6A	230/3	2	1.34 (34)	0.34 (9)	138**	GGC	0.173	4.42
	460/3	6	1.01 (26)	0.21 (5)	79**			0.45
	575/3						4.68	
	380/3						1.05 (27)	

NOTE: * Amp Rating at 30°C (86°F)
 ** Amp Rating at 40°C (104°F)

◆ Canada Use Type SOW Cable

Table B-4. Pump Power Cable Specifications (Continued)

Pump Model	Voltage/Phase	A.W.G Cable Size	Cable O.D. Inches (mm)	Conductor Dia. Inches (mm)	Amp Rating (See Note Below)	Cable Type	DC Resistance (ohms) at 225°C (77°F) per 1000 ft. (305 m)	Voltage Drop per 100 ft. (30,5m) at Max. Load
S6B	230/3	2/0	1.75 (44)	0.48 (12)	215**	GGC	0.09	3.78
	460/3	2	1.34 (34)	0.34 (9)	138**		0.17	3.57
	575/3							2.86
	380/3							2.58
	500/3	6	1.05 (27)	0.12 (5)	79**		0.45	5.22
S6C	230/3	2	1.34 (34)	0.34 (8)	138**	GGC	0.17	2.72
	460/3	6	1.01 (26)	0.21 (5)	79**		0.45	3.60
	575/3							2.88
	380/3		1.05 (27)					2.52
S6D	460/3	8	1.05 (27)	0.17 (4)	59**	SPC	0.71	5.47
	575/3							4.37
S6E	460/3	6	1.25 (32)	0.21 (5)	79**	SPC	0.45	5.94
	575/3							4.75
S8A	230/3	2/0	1.75 (45)	0.48 (12)	215**	GGC	0.09	3.78
	460/3	2	1.34 (34)	0.34 (9)	138**		0.17	3.57
	575/3							2.86
	380/3							2.75
S8B	460/3	1	1.51 (38)	0.38 (10)	161**	GGC	0.13	3.25
	575/3							2.60
	380/3	2	1.34 (34)	0.34 (9)	138**	0.17	3.26	
S8C	460/3	2/0	1.75 (45)	0.48 (12)	215**	GGC	0.09	2.97
	575/3	1	1.51 (38)	0.38 (10)	161**		0.13	3.43
	380/3							2.99
S8D	460/3	(2) 2/0	1.75 (45)	0.48 (12)	215**	GGC	0.09	2.88
	575/3							2.30
S12A	460/3	(2) 2/0	1.75 (45)	0.48 (12)	215**	GGC	0.09	3.04
	575/3	1	1.51 (38)	0.38 (10)	161**		0.13	3.52

NOTE: * Amp Rating at 30°C (86°F)
 ** Amp Rating at 40°C (104°F)

◆ Canada Use Type SOW Cable

When necessary to change or connect the pump power cable to the control box, make certain the incoming power is **OFF** and **LOCKED OUT**. Make certain the control box is **PROPERLY GROUNDED** and that the electrical data on the control matches the motor name plate data.

Connect the pump power cable to the control box as shown in the wiring diagrams in the control box manual. Use conduit or cable clamps to secure the power cable to the control box. Make certain that all connections are tight and that cable entry points are rainproof.

NOTE

The power cable furnished with the pump includes three electrical conductors (white, red, and black), two grounding conductors (green) and one ground check conductor (yellow). The yellow ground check lead is used in conjunction with customer-supplied ground monitoring equipment. If this equipment is not used, the yellow lead should be used as a ground conductor.

Control Box Specifications



Any control box used to operate the pump must be approved by the Gorman-Rupp Company for the application.

Motor Cable Grounding Test



Do not connect the pump control cable to the control box or incoming voltage before verifying the pump ground; otherwise, personnel will be exposed to serious injury or death.

Using a volt-ohm meter, connect one lead to the motor cable green/yellow ground lead. Connect the other lead to an **uninsulated** point on the pump body. The test circuit should close.

If the test circuit does not close, there is a defect in the cable or motor which must be corrected.

Control Box Connections

This pump is shipped completely wired for the voltage shown on the name plate, and is ready for operation through an approved control box.

Ground and wire the control box in accordance with the instructions accompanying it.

NOTE


For reference, internal motor wiring connections are shown in the Maintenance and Repair manual.

Liquid Level Devices

The standard pump is **not** furnished with a means to automatically regulate liquid level. However, the pump may be controlled to perform filling or dewatering functions by using **either** of the following optional sensing devices (see Figure B-4):


- **Diaphragm Type:** two fixed-position sensors (upper and lower) each contain a diaphragm which flexes with changes in liquid level, thus activating an enclosed miniature switch.
- **Bulb (Float) Type:** a bulb raises or lowers (floats) with the liquid level, thus activating an enclosed miniature switch.

Models under 6 horsepower require an additional control box to incorporate liquid level controls. For models over 6 horsepower, the circuitry may be prewired as a factory option, or easily added to the standard control box in the field by qualified personnel. The unit is complete except for the remote float switches. For installation and operation, see the detailed instructions included with the optional package.



Liquid level devices **must** be positioned far enough apart to allow 10 minutes between starts. If the pump motor cycles more than 6 starts per hour, it will over-heat, resulting in damage to the motor windings or control box components.

Other types of liquid level devices may also be used. Consult the factory for the liquid level device best suited for your application.



If the pump requires liquid level devices, install the liquid level devices and connect them to the control box in accordance with the instructions accompanying the devices.




Figure B-4. Liquid Level Devices



The internal wiring of the sensing devices are different for filling and dewatering functions. Be sure to follow the instructions in-

cluded with the option before making wiring connections.

WIRING DIAGRAMS

Refer to the appropriate wiring diagram in the literature accompanying the control box when making electrical connections.

OPERATION – SECTION C

GENERAL INFORMATION

Review all SAFETY information in Section A.



This pump is designed to handle most non-volatile, non-flammable liquids. **Do not attempt to pump any liquids for which your pump is not approved, or which may damage the pump or endanger personnel as a result of pump failure. Consult the factory for specific application data.**

Follow the instructions on all tags, labels and decals attached to the pump.

Pump Performance



Since operation of the pump motor is dependent upon the quality and performance of the electrical controls, the pump warranty is valid only when controls have been specified or provided by The Gorman-Rupp Company.

Refer to the pump Specification Data Sheet or the accompanying Parts List Manual for the specific performance for your pump.

Control Box

A control box is provided to facilitate operation of the pump. It contains controls for starting and stopping the pump, and provides overload protection for the pump motor. The pump control (for models 10 horsepower and up) may be equipped with an optional automatic liquid level sensing device, in which case those circuits are also contained within the control box. Pump models under 6 horsepower

require an additional control box to incorporate liquid level controls.



The pump motor and control box are not designed to be explosion-proof. Do not operate in an explosive atmosphere. Any control box used to operate the pump must be approved by the Gorman-Rupp Company for the application. Improper location of a non-explosion proof control box could result in destruction of equipment, injury or death to personnel.

See the operating instructions furnished with the control box, and with other optional accessories and controls, before attempting to start the pump.

PUMP OPERATION

Liquid Temperature and Overheating.




Overheated pumps can cause severe burns and injury. If the pump becomes overheated:

1. Stop the pump immediately.
2. Lock out the power to the control panel to ensure that the pump will remain inoperative.
3. Allow the pump to completely cool if overheated.
4. Close the discharge valve (if used).
5. Refer to instructions in this manual before restarting the pump.

Overheating can occur if the pump is misapplied; if it is started more than 6 times within one hour; if the temperature of the liquid being pumped ex-

ceeds the temperature for which the pump was designed, if the control box fails to provide overload or thermal protection, or if the pump is operated against a closed discharge valve for an extended period of time.



Do not start the pump more than 6 times per hour. If the motor does not cool between starts it will overheat, resulting in damage to the motor windings.

As a safeguard against rupture or explosion due to heat, models equipped with oil-lubricated motors are fitted with a pressure relief valve which will open if vapor pressure within the pump motor reaches a critical point. Always terminate power to the pump and control before investigating pump or control box problems.



Approach the pump cautiously after it has been running. Although the motor is cooled by the liquid being pumped, normal operating temperatures can be high enough to cause burns. The temperature will be especially high if operated against a closed discharge valve. Never operate against a closed discharge valve for long periods of time.

If overheating does occur, stop the pump immediately and allow it to cool before servicing it. **Approach any overheated pump cautiously.**



Overheated pumps can cause severe burns and injuries. If overheating of the pump occurs:

1. **Stop the pump immediately.**

2. **Ventilate the area.**
3. **Allow the pump to completely cool.**
4. **Check the temperature before servicing.**
5. **Vent the pump slowly and cautiously**
6. **Refer to instructions in this manual before restarting the pump.**

If so equipped, it is recommended that the pressure relief valve assembly be replaced at each overhaul, or any time the pump motor overheats and activates the valve. **Never** replace this valve with a substitute which has not been specified or provided by the Gorman-Rupp Company.

Impeller Rotation

Check impeller rotation as follows before operation to ensure that the impeller is rotating in the correct direction.



While checking impeller rotation, secure the pump to prevent the power cable from coiling.

Suspend the pump from the lifting device fitted on the pump. Apply power briefly and note the direction of pump kickback. As viewed from the top, the pump should kick in a **counterclockwise** direction; this will indicate that impeller rotation is correct.

If the pump kicks in a **clockwise** direction, impeller rotation is incorrect. If the pump is powered by a three-phase motor, have a qualified electrician interchange the control box connections of any two pump motor power leads. Re-check pump kickback; it should now be in a counterclockwise direction.

If rotation is incorrect on a single-phase motor, contact the factory before installing the pump.



The electrical power used to operate this pump is high enough to cause injury or death. Make certain that incoming power is off and locked out before interchanging motor leads.




Figure C-1. Checking Pump Rotation


STARTING, STOPPING, AND OPERATIONAL CHECKS

Starting



Do not attempt to operate the pump until impeller rotation has been checked; improper rotation will affect pump performance and may damage the pump.

Follow the instructions accompanying the control box, start the pump, and run any recommended checks.



Never start the pump more than 6 times per hour. If the pump motor does not cool between starts, it will over-heat, resulting in damage to the motor windings.

Stopping

Follow the instructions accompanying the control box for stopping the pump.



On pumps equipped with a motor thermal protector, the integral thermal overload device will shut off the motor if the temperature rises above design limits. When the pump cools and the temperature falls below these limits, the motor will restart automatically. To avoid the hazards of an unexpected motor start-up, do not attempt to handle or service the pump unless all power to the motor has been shut off and locked out at the control box; otherwise, serious personal injury could result.


During motor shutoff by the thermal overload device, control box circuits remain live. Do not attempt to service any control box components unless incoming power has been shut off.

To stop the pump, turn the control handle OFF, thereby opening the circuit breakers. This **does not** terminate incoming power through the field wiring connected to the control box.

After stopping the pump, be sure to perform all required maintenance and preservation procedures.

Operational Checks

To detect minor problems, check the pump for proper operation when it is first started, and at periodic intervals during operation.



To avoid serious damage to the pump, check for unusual noises or excessive vibration while the pump is running. If noise or vibration is excessive, stop operation and refer to the troubleshooting chart in the maintenance and repair manual.

The suction inlet or impeller may become clogged with debris. In some cases, stopping the pump momentarily may backflush this blockage. If backflushing does not clear the debris, remove the pump from the sump or wet well and clear manually.



Never introduce air or steam pressure into the pump casing to remove a blockage. This could result in personal injury or damage to the equipment. If backflushing is absolutely necessary, limit liquid pressure input to 50% of the maximum permissible operating pressure shown in the pump performance curve (refer to the accompanying Parts List Manual).

Check the pump for overheating. Overheating can occur if the pump is misapplied, required to start repeatedly, if the control box fails to provide overload or thermal protection, or if the pump is operated against a closed discharge valve for an extended period of time.



Do not start the pump more than 6 times per hour. If the motor does not cool between starts it will overheat, resulting in damage to the motor windings.

Check the oil level(s) as indicated in the following **LUBRICATION** section.

COLD WEATHER PRESERVATION



Do not attempt to thaw the pump by using a torch or other source of flame. This could damage gaskets, O-rings or heat the oil in the seal housing above critical temperatures, causing the pump to rupture or explode.

The pump will not freeze as long as the casing is submerged in liquid. If the casing is not submerged, or if the liquid begins to freeze, remove the pump from the sump or wet well and dry it thoroughly. Run the pump for two or three minutes to dry the inner walls.

If the pump does freeze while it is out of the liquid, submerge it until thawed; if the liquid is near freezing, the pump must be submerged for an extended period of time. Check thawing by starting the pump and checking that the shaft rotates freely. If the pump remains frozen, allow additional thawing time before attempting to restart.

If submerging does not thaw the pump, move it into a warm area until completely thawed.

LUBRICATION



Do not remove plates, covers, gauges, pipe plugs or fittings from an overheated pump. Vapor pressure within the pump can cause parts being disengaged to be ejected with great force. Allow the pump to completely cool before servicing.

On a new pump, check the oil level in both seal and motor cavities (if oil lubricated) before initial start-up, and drain and replace the oil after the first 200 hours of operation. Following this, check the oil level in the seal cavity after the first two weeks of op-

eration, and every month thereafter. Check the motor lubrication level any time the pressure relief valve is activated, and replace the oil annually.

Before installing or removing the lubrication plug(s), always clean the area around the plug(s) to prevent contamination.

Draining Oil

Refer to the Parts List Manual for drain plug location.

For the smaller pump, lay the pump horizontal on a flat work surface with the seal cavity drain plug facing up. Remove the drain plug slowly to release any pressure. Install a short pipe nipple in the hole. Place a clean container under the plug and roll the pump on its side to drain the seal housing.

For the larger pump, remove the drain plug slowly to release any pressure. Install a short pipe nipple in the hole. Place a clean container under the plug and using a hoist, tilt the pump at an angle of approximately 60 degrees.

If the motor is oil-cooled, repeat the procedure for the motor housing oil.

Condition Of Oil

Check the condition of the oil drained from the pump. Clear oil indicates that the pump seal(s) are functioning properly. If the oil is milky or contains a small amount of water, it must be changed.

If the oil contains a large amount of water, it must be changed, and the seal(s) must be checked be-

fore the pump is put back in operation (refer to the Maintenance and Repair Manual).

Adding Oil

Due to differences in pump design, the quantity of oil and manner in which oil is to be added to the seal cavity varies between pump models. Refer to Table B-2 in **INSTALLATION** for oil capacities and positions for filling the seal cavity in each pump. Motor cavities requiring lubrication should always be positioned vertically for filling.

The grade of lubricant used is critical to the operation of this pump. Use premium quality submersible pump oil as specified in the following table. Oil must be stored in a clean, tightly closed container in a reasonably dry environment.

When lubricating the seal cavity, remove the lubrication plug as indicated in **Draining Oil**, and position the pump as indicated in Table B-2. Add premium quality submersible pump oil through this plug hole. If the pump is to be positioned vertically or at an angle, fill the cavity to the bottom of the plug hole. If the pump is to be positioned horizontally, completely fill the cavity.

Install and tighten the lubrication plug.

When lubricating the motor cavity, add oil through the hole for the pressure relief valve. If the pump is equipped with a motor lubricant level plug, remove this plug and fill the cavity until oil escapes through the hole. If the pump is not equipped with a motor lubricant level plug, fill the cavity to the top of the hole.

Reinstall the pressure relief valve.

Table C-1. Pump Oil Specifications

Specifications:	
Type	Premium high viscosity index, anti-wear hydraulic oil
Viscosity @ 100°F (38°C)	110 to 155
Viscosity @ 210°F (99°C)	40 to 50
Dielectric	26,000 (volts-min)
Recommended supplier:	
Gulf Oil Company	Gulf Harmony HVI AW 26
Acceptable alternate suppliers:	
Gulf Oil Company	Gulf Harmony 32 AW
Texas Oil Company	Rando HD 32 or HD AZ 32
Sun Oil Company	Sunvis 816 or 916
BP (Also Boron)	Energol-HLP 32
Shell Oil Company	Tellus 32, Tellus T-23 or T32
ARCO	Duro 32
Exxon (Also Esso)	Nuto H 32
Petro-Canada	Harmony HVI 22

TROUBLESHOOTING – SECTION D

Review all SAFETY information in Section A.



The following precautions should be taken before attempting to service the pump; otherwise, injury or death could result.

1. Familiarize yourself with this manual and with all other literature shipped with the pump.
2. Lock out incoming power to the pump or control box to ensure that the pump will remain inoperative.
3. Allow the pump to completely cool if overheated.
4. Check the temperature before opening any covers, plates or plugs.

5. Close the discharge valve (if used).



The electrical power used to operate this pump is high enough to cause injury or death. Obtain the services of a qualified electrician to troubleshoot, test and/or service the electrical components of this pump.

NOTE

*Many of the probable remedies listed below require use of electrical test instruments; for specific procedures, see **ELECTRICAL TESTING** following the chart.*

Table 1. Trouble Shooting Chart

TROUBLE	POSSIBLE CAUSE	PROBABLE REMEDY
PUMP FAILS TO START, OVERLOAD UNIT NOT TRIPPED (MANUAL MODE) (AUTOMATIC MODE)	Power source incompatible with control box.	Correct power source.
	No voltage at line side of circuit breaker.	Check power source for blown fuse, open overload unit, broken lead, or loose connection.
	Open circuit in motor windings or power cable.	Check continuity.
	Defective motor power cable.	Replace cable.
	Motor defective.	Check for and replace defective unit.
	Liquid level device or control circuits improperly connected to main control box.	Check wiring diagrams; correct or tighten connections.
Level sensing device(s) improperly positioned.	Position device(s) at proper level.	
Level sensing device(s) fouled with mud or foreign material.	Clean sensing device(s).	

Table 1. Trouble Shooting Chart (cont.)

TROUBLE	POSSIBLE CAUSE	PROBABLE REMEDY
(AUTOMATIC MODE) (CONT'D.)	Float type sensing device(s) tangled or obstructed.	Check installation for free movement of float.
	Defective liquid level sensing device(s) or control panel.	Repair or replace defective unit(s).
OVERLOAD UNIT TRIPS	Low or high voltage, or excessive voltage drop between pump and control box.	Measure voltage at control box. Check that wiring is correct type, size, and length. (See Field Wiring Connections , Section B).
	Defective insulation in motor windings or power cable; defective windings.	Check insulation resistance; check continuity.
	Impeller jammed due to debris or insufficient clearance.	Disassemble pump and check impeller.
	Bearing(s) frozen.	Disassemble pump and check bearing(s).
MOTOR RUNS, BUT PUMP FAILS TO DELIVER RATED DISCHARGE	Discharge head too high.	Reduce discharge head, or install staging adaptor and additional pump.
	Low or incorrect voltage.	Measure control box voltage, both when pump is running and when shut-off.
	Discharge throttling valve partially closed; check valve is installed improperly.	Open discharge valve fully; check piping installation.
	Discharge line clogged or restricted; hose kinked.	Check discharge lines; straighten hose.
	Liquid being pumped too thick.	Dilute liquid by heating if possible.
	Strainer screen or impeller clogged.	Clear clog(s). Stop pump; back flow may flush away debris.
	Insufficient liquid in sump or tank.	Stop pump until liquid level rises.
	Worn impeller vanes; excessive impeller clearance.	Check impeller and clearance. See PUMP END REASSEMBLY .
Pump running backwards.	Check direction of rotation and correct by interchanging any two motor leads at control box. (See Pump Rotation , Section C).	

Table 1. Trouble Shooting Chart (cont.)

TROUBLE	POSSIBLE CAUSE	PROBABLE REMEDY
PUMP RUNS WITH EXCESSIVE NOISE OR VIBRATION	Pumping entrained air.	Check liquid level in sump; check position of pump and liquid level sensing device(s).
	Damaged or unbalanced impeller.	Replace impeller.
	Discharge piping not properly supported.	Check piping installation.
	Impeller jammed or loose.	Check impeller.
	Motor shaft or bearings defective.	Disassemble pump and check motor and bearings.
	Pump cavitation.	Reduce discharge head, or restrict flow on low head applications.

ELECTRICAL TESTING

If you suspect that pump malfunctions are caused by defects in the motor, power cable or control box, perform the following checks to help isolate the defective part.

Equipment	Use
Ammeter	To check AC Voltage and current (amperage)
Ohmmeter	To measure resistance (ohms) to ground

**WARNING!**

Obtain the services of a qualified electrician to troubleshoot, test and/or service the electrical components of this pump.

**CAUTION**

Be certain to refer to the wiring diagram(s) in the Installation Section of this manual before reconnecting any electrical components which have been disconnected.

Test Equipment

A volt/amp/ohmmeter and megohmmeter of adequate range and quality will be required to conduct the following electrical tests. The suggested equipment indicated below is commercially available, or an equivalent substitute may be used.

Voltage Imbalance

Each phase of the incoming three-phase power must be balanced with the other two as accurately as a commercial voltmeter will read. If the phases are balanced, check out the motor as described below. If the phases are out of balance, contact your power company and request that they correct the condition.

- a. Use a voltmeter, amprobe, or equivalent meter to read the voltage across terminals 1 & 2, 2 & 3, and 1 & 3 in the control box. All three measured voltages must be the same, as accurately as the meter will read. If possible, measure the voltage with the pump off, with the pump running but out of the water, and with the pump running in the water at full load. All the measured voltages at each condition must be the same.
- b. Use an amprobe or equivalent meter to measure the current draw of each phase while the pump is running at full load and at no load. All three amperage readings must

be the same at each condition, as accurately as the meter will read. Nominal amperage values are listed in Table 1, but these apply only when the actual voltage at the site is the nominal voltage listed.

- c. If the voltages are balanced with the pump off, but are unbalanced when the pump is running, a thorough check of the power source, all interconnecting cables, and the pump motor is required to isolate the defect.

Motor And Motor Power Cable Continuity

To check continuity, zero-balance the ohmmeter set at the RX1 scale, and test as follows:

- a. Disconnect the motor power cable leads from the control box and connect the test leads to any two of the three power cable leads (not to the green ground lead or yellow ground check lead). If there is a high resistance reading on the ohmmeter, there is an open or broken circuit caused by a break in the power cable or motor windings, or by a bad connection between the motor and the power cable. Switch one test lead to the third power lead, and test again.
- b. If an open or broken circuit is indicated, check the power cable for obvious damage, and replace as necessary (see **MAINTENANCE AND REPAIR**). If there is no apparent damage to the motor cable, remove the terminal housing (see **MAINTENANCE AND REPAIR**) and check the continuity of each power cable lead at the terminal posts.

NOTE

When shipped from the factory, the connections between the power cable leads and the terminal posts were encapsulated in heat shrink tubing and bonded to the terminal plate to provide a water tight seal. In service, these connections may have been potted by the pump operator. Do not cut the tubing or potting away unless absolutely necessary. Check the continuity of each lead from the motor side of the terminal plate. If the continuity is good, there is no need to remove the tubing or potting material. If there is no continuity through the lead, remove the tubing or potting from only that terminal, and check for a loose connection. Be sure to re-

*place the tubing or potting and allow adequate drying time before putting the pump back into service. (See **Power Cable Reassembly**, Section E).*

- c. If an open circuit still exists after each lead (terminal) has been tested and tightened, then the **entire** motor power cable must be replaced. Splicing or other means of repair are not recommended.
- d. If no break is found in the power cable, check the motor leads for continuity. If the test reading indicates an open or broken circuit, there is an open circuit in the motor.

NOTE

It is recommended that a pump with a defective motor be returned to Gorman-Rupp, or to one of the Gorman-Rupp authorized Submersible Repair Centers.


Insulation Resistance

To check insulation, zero-balance the ohmmeter set at the RX100K scale, and test as follows:

- a. Disconnect the motor power cable leads from the control box. Connect one test lead to the power cable green ground lead, and touch the other test lead to each of the three power leads in turn.
- b. The reading obtained will indicate resistance values in both the power cable and the motor windings. If the resistance reading is infinity (∞), the insulation is in good condition. If the reading is between infinity (∞) and 1 megohm, the insulation is acceptable but should be rechecked periodically. If the reading is less than 1 megohm, the insulation should be checked more closely; a reading of zero indicates that the power cable or the motor is grounded.
- c. To determine whether the power cable or the motor is grounded, remove the terminal housing (see **MAINTENANCE AND REPAIR**), disconnect the motor leads from the motor terminals, and test the power cable leads and motor leads separately.

PUMP MAINTENANCE AND REPAIR - SECTION E

MAINTENANCE AND REPAIR OF THE WEARING PARTS OF THE PUMP WILL MAINTAIN PEAK OPERATING PERFORMANCE.



Performance Curve – Model S6E1–E60 460/575/3

* Based on 70° F (21° C) clear water at sea level. Since pump installations are seldom identical, your performance may be difference due to such factors as viscosity, specific gravity, elevation, temperature, and impeller trim.

If your pump serial number is followed by an “N”, your pump is **NOT** a standard production model. Contact the Gorman-Rupp Company to verify performance or part numbers.

SECTION DRAWING




Figure 1. Pump Models S6E1-E60 460/3 & S6E1-E60 575/3

PARTS LIST

Pump Model S6E1-E60 460/3 & S6E1-E60 575/3

(From S/N 1821479 Up)

If your pump serial number is followed by an "N", your pump is **NOT** a standard production model. Contact the Gorman-Rupp Company to verify part numbers.

ITEM NO.	PART NAME	PART NUMBER	QTY	ITEM NO.	PART NAME	PART NUMBER	QTY
1	DIFFUSER	38632-059 1102H	1	35	ROTOR & SHAFT ASSY	47112-047	1
2 *	IMPELLER	38628-540 1102H	1	36 *	LOWER BALL BEARING	23425-462	1
3 *	LOWER SEAL ASSY	46512-056	1	37	LOWER MOTOR HSG	38311-306 13040	1
4 *	UPPER SEAL ASSY	25271-903	1	38	HEX HD CAPSCREW	B0605 15991	4
5	SOC HD PIPE PLUG	PC24 17000	1	39	DYNA SEAL WASHER	S1586	4
6	SEAL DRAIN/FILL PLUG	PC06 17000	1	40	PIPE PLUG	P06 15079	1
7	BEARING CAP	38322-421 13040	1	41	SEAL PLATE O-RING	S1990	1
8	HEX HD CAPSCREW	B1008 17000	6	42	SEAL PLATE	38272-526 1102H	1
9	LOCK WASHER	J10 17000	6	43 *	MTR HOUSING O-RING	25152-282	1
10 *	LWR MTR HSG O-RING	S1676	1	44 *	IMPELLER KEY	N0405 17000	1
11 *	STATOR KEY	N0812 17000	1	45 *	IMPELLER WASHER	31131-026 17000	1
12	MOTOR HOUSING	38311-809 13000	1	46 *	IMPELLER NUT	AT14S 17000	1
13	UPPER MOTOR HSG	38311-316 13000	1	47 *	SUCT HEAD O-RING	25152-367	1
14 *	UPPER BALL BEARING	23282-010	1	48	WEAR RING	38691-325 14000	1
15 *	MTR HOUSING O-RING	25152-282	1	49	SUCTION HEAD	38247-405 10000	1
16 *	IMP ADJ SHIM SET	37J 17090	1	50	STRAINER SUPPORT	31412-076 15079	6
17	RETAINING RING	S245	1	51	STRAINER ASSY	46611-014 2415V	1
18 *	SPRING HOLDER	25273-273	1	52	STUD	C0842 15991	6
19	HEX HD CAPSCREW	B1208 15991	2	53	LOCK WASHER	J08 15991	6
20	LOCK WASHER	J12 15991	2	54	HEX NUT	D08 15991	6
21	FLAT WASHER	K12 15991	2	55	BASE PLATE	38352-306 13080	1
22	BUSHING	10045 15071	2	56	HEX HD CAP SCREW	B0804 15991	5
23	HOISTING BAIL ASSY	44713-026 2415V	1	57	LOCK WASHER	J08 17000	5
24 *	DISCH FLANGE GASKET	38687-049 20000	1	58	HEX HD CAP SCREW	B1020 17000	6
25	DISCHARGE FLANGE	38642-207 10010	1	59	LOCK WASHER	J10 17000	6
26	PIPE PLUG	P04 17000	1	60	HEAT SHRINK TUBE - 5"	18763-249	1
27	STUD	C0809 15991	6	NOT SHOWN:			
28	HEX NUT	D08 15991	6	CONTROL BOX:			
29	NAME PLATE	2613GH 17020	1	-460V	27515-525	1	
30	DRIVE SCREW	BM#04-03 17000	2	-575V	27515-535	1	
31	TERM HSG/CABLE ASSY	47367-079	1	HEATER PACK:			
32	STUD	C0607 15991	4	-460/3	27521-211	1	
33	DEFORM LOCKNUT	DD06 15991	4	-575/3	27521-210	1	
34	STATOR ASSY:			IMPELLER PULLER	48711-018	1	
-460V	47113-047	1	INSTRUCTION TAG	38817-073	1		
-575V	47113-048	1	SUB. PUMP OIL	9568	1		

* INDICATES PARTS RECOMMENDED FOR STOCK

SECTION DRAWING




Figure 2. 47367-079 Terminal Housing And Cable Assembly

PARTS LIST
47367-079 Terminal Housing And Cable Assembly

ITEM NO.	PART NAME	PART NUMBER	QTY
1	TERMINAL GLAND	38381-614 13040	1
2	CABLE - 50 FT	47325-006	1
3	CABLE GRIP	11227K	1
4	STUD	C0808 15991	2
5	HEX NUT	D08 15991	2
6	GLAND BUSHING	31143-067 19100	1
7	TERMINAL WASHER	31133-122 15991	1
8	TERMINAL HOUSING	38381-237 13000	1
9	TERMINAL	27214-035	1
10	HEAT SHRINK TUBE	31412-056 19530	2
11	ALLEN HEAD SETSCREW	GA#10-01S 15991	2
12	TERMINAL COLLAR	31811-057 14100	2
13	* DYNA SEAL WASHER	S1590	2
14	* DYNA SEAL WASHER	S1590	2
15	TERMINAL POST	11181 14100	2
16	ALLEN HEAD SETSCREW	GA#10-01S 15991	2
17	TERMINAL POST	38724-009 14100	3
18	ALLEN HEAD SETSCREW	GA0501 -1/2 14990	3
19	* DYNA SEAL WASHER	S1586	3
20	* DYNA SEAL WASHER	S1586	3
21	* TERMINAL PLATE GSKT	38687-529 20000	1
22	TERMINAL PLATE	38711-001 23010	1
23	* TERMINAL PLATE GSKT	38687-529 20000	1
24	TERMINAL COLLAR	10144 14100	3
25	ALLEN HEAD SETSCREW	GA0501- 1/2 14990	3
26	* O-RING	25152-155	1
27	HEAT-SHRINK TUBE	31413-014 19530	3
28	TERMINAL	S1550	1
29	RD HD MACHINE SCREW	X0603 14990	2
30	T TYPE LOCKWASHER	AK06 15991	2
31	DRIVE SCREW	BM#04-03 17000	4
32	INFORMATION PLATE	38816-145 17050	1
NOT SHOWN:			
	RTV SEALANT - 1 OZ.	18771-106	1
OPTIONAL:			
	HEAT SHRINK TERMINAL KIT	48315-010	1

* INDICATES PARTS RECOMMENDED FOR STOCK

PUMP AND SEAL DISASSEMBLY AND REASSEMBLY

References are to Figure 1 and Figure 2.

Review all SAFETY information in Section A.

Follow the instructions on all tags, label and decals attached to the pump.

Before attempting to service the pump or control, terminate the power supply to the control box. Close the discharge throttling valve, if so equipped.



The electrical power used to operate this pump is high enough to cause injury or death. Make certain that the control handle on the control box is in the OFF position and locked out, or that the power supply to the control box has been otherwise cut off and locked out, before attempting to open or service the pump assembly. Tag electrical circuits to prevent accidental start-up.

Use the hoisting bail to remove the pump from the wet well or sump, and move it to a location where the discharge line can be removed. It is not necessary to disconnect a flexible discharge hose before removing the pump. If rigid discharge piping is used, disconnect the piping before attempting to move the pump.



Do not attempt to lift the pump by the motor power cable or the piping. Attach proper lifting equipment to the lifting device fitted to the pump. If chains or cable are wrapped around the pump to lift it, make certain that they are posi-

tioned so as not to damage the pump, and so that the load will be balanced.

Select a suitable location, preferably indoors, to perform the degree of maintenance required. If the motor housing is to be opened, the work must be done in a clean, well-equipped shop. All maintenance functions must be done by qualified personnel.

Check the chart in **TROUBLESHOOTING**, Section B of this manual, to determine the nature of the pump problem. If the problem is mechanical in nature, such as worn pump parts, seal replacement, lubrication, etc., refer to **PUMP END DISASSEMBLY** for instructions.

If the problem is electrical, complete disassembly may not be required. Refer to **Electrical Testing** in **TROUBLESHOOTING**, Section B, and have a qualified electrician check the control box, cable and terminal housing. If the problem is determined to be in the motor, proceed with **PUMP END DISASSEMBLY**, followed by **MOTOR DISASSEMBLY**. Otherwise, see **Terminal Housing And Power Cable Disassembly**.

Carefully inspect any O-rings or gaskets before removal and cleaning to determine if a proper seal and compression existed prior to disassembly. If sealing was faulty or questionable, the cause must be determined and corrected before reassembly. All gaskets and most O-rings **must** be replaced if disturbed. Repair gaskets and O-rings are listed in the Parts List manual.

PUMP END DISASSEMBLY

Strainer Removal


(Figure 1)

To remove the strainer assembly (51), raise the pump slightly, or lay it on its side and disengage the hardware (53 and 54) securing the base plate (55) and strainer assembly to the diffuser (1). Remove the base plate, strainer and supports (50).

Draining Oil From Seal Cavity

(Figure 1)

If any further disassembly is to be performed on the pump, the seal oil cavity must be drained.



Let the pump cool before removing the seal cavity drain plug. Pressure built up within a hot pump could cause the oil to spray out when the plug is removed. Remove the plug slowly and permit pressure to vent to atmosphere.

Lay the pump on its side with the pipe plug (5) facing up. Clean any dirt from around the plug and remove it. Remove the seal cavity drain plug (6), and install a short 3/8-inch NPT nipple in the hole. Tip the pump and drain the seal oil into a **clean** container. Inspect the oil for water, dirt, or cloudy condition which could indicate lower seal failure or poor gasket seal.

Positioning Pump For Disassembly

(Figure 1)


It is recommended that the pump be positioned upside-down during disassembly. To hold the pump in the inverted position, rest the pump securely on blocks. Be careful not to damage the terminal housing and cable assembly (31) while in this position. Use adequate equipment and personnel to safely handle the pump until it is secured. If inverting the pump is not practical, lay the pump on its side and secure it to prevent rolling.

Suction Head And Wear Ring Removal

(Figure 1)

Remove the hardware (56 and 57) securing the suction head (49) to the diffuser (1). Remove the suction head, and remove and discard the diffuser O-ring (47).

Inspect the wear ring (48) for excessive wear or scoring. If replacement is required, drill two holes horizontally 180° apart, through the wear ring. Use a chisel or other suitable tool to complete the cuts and remove the wear ring from the suction head. **Be careful** not to damage the suction head bore.



Use caution not to damage the suction head when removing the wear ring.

Diffuser Removal

(Figure 1)

Disengage the hardware (58 and 59) securing the diffuser (1) to the seal plate (42) and lower motor housing (37). Remove the diffuser and motor housing O-ring (43), and discard the O-ring. If the impeller (2) is clogged, the debris can usually be removed without further disassembly.

Impeller Removal

(Figure 1)

Temporarily install two of the capscrews (58). Wedge a block of wood between the vanes of the impeller (2) and the capscrews to prevent impeller rotation. Remove the impeller nut (46) and washer (45). Remove the piece of wood from between the vanes of the impeller and remove the capscrews.

Install the impeller puller (supplied with the pump) and pull the impeller from the rotor shaft. Use caution when removing the impeller; tension on the seal spring will be released. Retain the impeller key (44). Inspect the impeller for wear or damage and replace as required.

Remove the impeller adjusting shims (16). Tie and tag the shims or measure and record their thickness for ease of reassembly.

If no further disassembly is required, proceed to the appropriate areas in **PUMP END REASSEMBLY**.

Lower Seal Removal

(Figures 1 and 3)

Carefully remove the seal spring. Lubricate the rotor shaft and work oil under the bellows assembly. Use the hooked ends of two stiff wires to pull the rotating portion of the seal from the shaft.

To remove the stationary portion of the seal, pry the seal plate (42) and O-ring (41) out of the lower mo-

tor housing (37) and off the shaft. Remove and discard the seal plate O-ring (41).


Place a **clean** cloth on a flat surface and place the seal plate on the cloth with the impeller side down. Use a drift pin or suitably sized dowel to press the stationary seat and element out of the seal plate.

If no further disassembly is required, proceed to the appropriate areas in **PUMP END REASSEMBLY**.

Upper Seal Removal

(Figures 1 and 4)

Unless cracked or otherwise worn, it is not necessary to remove the lower motor housing (37) for access to the upper seal assembly (4).



If the lower motor housing must be removed, see the procedure under **Motor Disassembly** in this section. **Do not** attempt to loosen the hardware (38 and 39) securing the bearing cap (7) before referring to this section; otherwise, the rotor shaft and bearings could be damaged.

Remove the seal retaining ring (17) using snap ring pliers. Use caution when removing the retaining ring; tension on the seal spring will be released. Remove the spring holder (18) and seal spring.

Lubricate the rotor shaft (35) and work oil under the bellows. Use a pair of stiff wires with hooked ends to pull the rotating portion of the seal off the shaft.

Slide the hooked ends of two wires along the shaft and under the stationary seal seat. Hook the back side of the seat and pull it from the lower motor housing bore.

If no further disassembly is required, proceed to the appropriate areas in **PUMP END REASSEMBLY**.

NOTE

Do not disassemble the motor unless it is necessary and a clean, well-equipped shop is available. If

*the motor housing components are to be serviced, see **MOTOR DISASSEMBLY** in this section. Do not reassemble the end components at this time.*

PUMP END REASSEMBLY

NOTE

Reuse of old O-rings, gaskets, or shaft seal parts will result in premature leakage or reduced pump performance. It is strongly recommended that new gaskets and shaft seal assemblies be used during reassembly (see the parts lists for numbers).

Cleaning And Inspection Of Pump Parts

(Figure 1)

With the pump inverted, stuff a clean tissue into the stationary seal seat bore of the lower motor housing (37) or wrap a small rag around the shaft to prevent foreign material from entering the motor cavity.

Carefully inspect any O-rings or gaskets before removal and cleaning to determine if a proper seal and compression existed prior to disassembly. If sealing was faulty or questionable, the cause must be determined and corrected before reassembly. Replace any parts as required.

Thoroughly clean all reuseable parts with a soft cloth soaked in cleaning solvent. Remove all O-rings and gaskets, and clean the sealing surfaces of dirt or gasket material. Be careful not to scratch gasket surfaces. Use a clean cloth lightly dampened with solvent to clean the lower motor housing and seal plate. **Do not** allow the solvent to enter the motor.



Most cleaning solvents are toxic and flammable. Use them only in a well ventilated area free from excessive heat, sparks, and flame. Read and follow all precautions printed on solvent containers.

Inspect the rotor shaft (35) for damaged threads, scoring, or nicks. Remove nicks and burrs with a fine file or emery cloth to restore original contours. If the shaft is bent or severely damaged, the rotor and shaft must be replaced as an assembly (see **MOTOR DISASSEMBLY**).

Neither of the shaft seal assemblies (3 or 4) should be reused because wear patterns on the finished faces cannot be realigned during reassembly. This could result in premature failure. If necessary to reuse an old seal in an **emergency**, **carefully** wash all metallic parts in fresh cleaning solvent and allow to dry thoroughly.

Handle the seal parts with extreme care to prevent damage. Be careful not to contaminate the precision finished faces; even fingerprints on the faces can shorten seal life. If necessary, clean the faces with a non-oil based solvent and a clean, lint-free tissue. Wipe **lightly** in a circular pattern to avoid scratching the faces.

Inspect the seal components for wear, scoring, grooves, and other damage that might cause leakage. If any components are worn, replace the complete seal; **never mix old and new seal parts**.

Install the shaft seals as illustrated in Figure 3.




Figure 3. Upper And Lower Seal Assemblies



This seal is not designed for operation at temperatures above 122° F (50° C). Do not use at higher operating temperatures.

Upper Seal Installation

(Figures 1 and 3)

Do not unwrap a new seal assembly until time of installation. Cleanliness of seal components is critical, especially the seal faces.

Carefully remove the material stuffed into the seat bore (or unwrap the shaft). **Be sure** no debris stopped by the material falls into the seal cavity.

Clean the rotor shaft (35) and seal cavity area of the lower motor housing (37). Be sure the area is dry and free of lint and dirt. Check the seal bore for burrs or nicks that might prevent a good seal. Remove them with a fine file or emery cloth to restore original contours. If the shaft is bent or damaged, the complete rotor and shaft must be replaced as an assembly. Apply a **light** coating of oil to the bore of the lower motor housing.

NOTE

When pressing seal components onto the shaft, use hand pressure only. A push tube cut from a length of plastic pipe will aid in installing seal components. The I.D. of the push tube should be approximately the same as the I.D. of the seal spring.

Position the seat in the lower motor housing bore with the sealing face up and cover the seal face with a clean tissue. Use your thumbs to press the seat into the bore. Apply equal pressure on opposite sides until the seat is fully seated in the bore. Remove the tissue and inspect the seal face to ensure that it is clean and dry. If cleaning is necessary, use clean tissue to wipe **lightly** in a circular pattern.

Unpack the rotating portion of the seal. Be certain the seal face of the rotating element is free of grit or surface damage. Because the rotating element may not stay in the bellows retainer when turned upside down, place a **small** amount of grease at equal spaces on the back of the element and position it in the bellows retainer. The grease should hold the element in position until the seal is installed. Assemble the drive grooves of the rotating element into the drive lugs of the bellows retainer.

Apply a **light** coating of oil to the seal seating surface on the shaft, the groove for the retaining ring (17), and I.D. of the bellows. Apply a single drop of **light** lubricating oil to the precision finished seal face.

Position the rotating seal portion on the shaft with seal face down. Apply firm steady pressure on the bellows retainer until it slides down the shaft and

the seal faces contact. This step should be done in one continuous motion to prevent the bellows from sticking or rolling as it passes over the retaining ring groove.

Slide the seal spring over the shaft and bellows retainer, and install the spring holder (18). Install the seal retaining ring (17). See Figure 3 for the proper order of seal assembly.

Lower Seal Installation

(Figures 1 and 3)

Thoroughly clean the O-ring surfaces and seal bore of the seal plate (42). The seal bore must be free of burrs and nicks which could damage the seal. Inspect the seal plate for cracks, distortion, or erosion and replace it if defective.

Position the seal plate on a clean flat surface with the impeller side up.

Unpack the stationary seat and element. Subassemble the stationary element in the stationary seat. Apply a **light** coating of oil to the seal plate bore and the O.D. of the seal seat and O-ring. Keep the sealing face dry.

Position the subassembly in the seal plate bore, and cover it with a clean tissue. Use your thumbs to press the seat into the bore. Apply equal pressure on opposite sides of the seat until it is fully seated in the bore. Remove the tissue and inspect the seal face to ensure that it is clean and dry. If cleaning is necessary, use clean tissue to wipe **lightly** in a circular pattern.

NOTE

When pressing seal components onto the rotor shaft, use hand pressure only. A push tube cut from a length of plastic pipe will aid in installing seal components. The I.D. of the push tube should be approximately the same as the I.D. of the seal spring.

Install the seal plate O-ring (41) on the seal plate. Carefully position the seal plate and stationary seal components on the rotor shaft and press the seal plate into the lower motor housing until fully seated. **Be careful** not to damage the stationary element already installed.

Unpack the rotating portion of the seal. Be certain the seal face of the rotating element is free of grit or surface damage. Because the rotating element may not stay in the bellows retainer when turned upside down, place a **small** amount of grease at equal spaces on the back of the element and position it in the bellows retainer. The grease should hold the element in position until the seal is installed. Assemble the drive grooves of the rotating element into the drive lugs of the bellows retainer. Apply a **light** coating of oil on the shaft and the I.D. of the bellows.

Slide the seal rotating portion onto the lubricated shaft with the seal face down. Apply firm, steady pressure on the bellows retainer until it slides down the shaft and the seal faces contact.

Slide the seal spring over the shaft and bellows retainer. See Figure 3 for proper order of seal assembly.

Impeller Installation

(Figure 1)

Inspect the impeller (2) for cracks, broken vanes, or wear from erosion, and replace it if damaged. Clean the threads on the rotor shaft to remove any old thread locking material. Be sure the impeller bore and the shaft are free of oily film and completely dry.

Install the same thickness of impeller adjusting shims (16) as previously removed. Install the impeller key (44). Align the keyway of the impeller (2) and push the impeller onto the shaft until seated firmly against the impeller shim set. Install the impeller washer (45) on the rotor shaft (35).

After the impeller clearance has been checked as described below, coat the threads of the rotor shaft with 'Loctite Threadlocker No. 242' or equivalent compound. Install the impeller nut (46). Install two capscrews (58) in the seal plate. Wedge a block of wood between the vanes of the impeller and the capscrews and torque the nut to 120 ft. lbs. (1440 in. lbs. or 17 m. kg.).

Remove the block of wood and capscrews. Turn the impeller to check for free rotation.

Diffuser Installation

(Figure 1)

Inspect and thoroughly clean the diffuser (1) and its O-ring groove. It must be clean and free of any flaws which could cut the O-ring or prevent a good seal. Lightly oil the O-ring (47) and install it in the groove of the diffuser.

Carefully position the diffuser over the seal plate and motor housing and press it into the motor housing until fully seated. Secure the diffuser with the hardware (58 and 59). Torque the capscrews evenly in a cross sequence to 120 ft. lbs. (1440 in. lbs. or 16,6 m. kg.). After installing the diffuser, check the impeller for free rotation.

Impeller Clearance

(Figure 1)

For maximum pump efficiency, there should be a clearance of .020 to .040 inch (0,5 to 1,0 mm) between the seal plate and the back of the impeller. Use a feeler gauge to measure this clearance. If the clearance is not within the specific limits, remove the impeller and diffuser. Add or remove adjusting shims (16) as required. Install the impeller and diffuser and recheck impeller clearance.

Suction Head And Wear Ring Installation

(Figure 1)

If the wear ring (48) was removed, position the replacement ring in the suction head with the chamfered end toward the bore shoulder. Press the wear ring into the suction head until fully seated.

NOTE

*The wear ring **must** seat squarely in the suction head; otherwise, binding and/or excessive wear will occur as the shaft turns.*

Install the O-ring (47) on the diffuser. Position the suction head (49) on the diffuser and secure it with the hardware (56 and 57). Apply 'Never-Seez' or equivalent compound on the threads of the capscrews (56). Torque the capscrews in a cross sequence to 40 ft. lbs. (480 in. lbs. or 5,5 m. kg.).

Strainer Installation

(Figure 1)

Inspect the strainer assembly (51) for cracks, distortion or erosion, and replace it if defective.

Install the strainer supports (50) and the strainer. Position the base plate (55) over the studs (52). Secure the assembly with the hardware (53 and 54). Tighten the nuts just enough to draw the strainer screen down tightly, but not tight enough to distort it. Make certain that the strainer seats properly against the shoulder of the diffuser.

See **LUBRICATION** and **FINAL ASSEMBLY** before putting the pump back into service.

MOTOR DISASSEMBLY

Disassembly of the motor is rarely required except to replace the motor rotor, stator or bearings. Do not disassemble the motor unless it is necessary and a clean, well-equipped shop is available.

NOTE

It is recommended that a pump with a defective motor be returned to Gorman-Rupp, or to one of the Gorman-Rupp authorized Submersible Repair Centers.



The electrical power used to operate this pump is high enough to cause injury or death. Make certain that the control handle on the control box is in the off position and locked out, or that the power supply to the control box has been otherwise cut off and locked out, before attempting to open or service the pump assembly. Tag electrical circuits to prevent accidental start-up.

Carefully inspect any O-rings or gaskets before removal and cleaning to determine if a proper seal and compression existed prior to disassembly. If sealing was faulty or questionable, the cause must

be determined and corrected before reassembly. Replace any parts as required.

Terminal Housing And Power Cable Removal And Disassembly

(Figure 1)

Total disassembly of the terminal housing and power cable (31) is not always required. Disassemble and replace **only** the parts proven defective by inspection or testing. See **Electrical Testing** in **TROUBLESHOOTING**.

The terminal housing and power cable assembly (31) may be serviced without disassembling the motor housing or pump end.

Secure the pump in an upright position. Remove the deform locknuts (33) securing the terminal housing assembly (31) to the upper motor housing assembly (13).

(Figure 2)

Carefully raise the terminal housing (8) from the motor housing until the terminals (15 and 17) are accessible. Loosen the allen head setscrews (16 and 18), and disconnect the motor leads from the terminal posts. Separate the terminal housing and power cable assembly (2) from the motor housing. Remove the lower terminal plate gasket (21).

Remove the O-ring (26) from the terminal housing. No further disassembly is required to test the stator or power cable.

To disconnect the power cable (2), remove the nuts (5) securing the terminal gland (1) to the terminal housing (8). Slide the gland back along the power cable. Oil the bushing (6) and terminal housing bore and pull firmly on the cable. (Allow the oil to leak in around the bushing by agitating the cable in the bore.) After the bushing has been loosened, the cable should pull out far enough to expose the bushing. Apply oil on the cable jacket and slide the bushing and washer (7) back along the cable. Quite often, pressure exerted on the bushing will deform the cable jacket. If such happens, additional oil and effort will be required to remove the bushing.

NOTE

If the rubber bushing cannot be removed from the

terminal housing as indicated, it may be necessary to cut the bushing into small pieces or cut the cable.

Push approximately 6 inches (152 mm) of the power cable into the terminal housing so that the terminal plate comes free of the terminal housing. This should permit access to the power cable connections in the terminal plate.

NOTE

Do not remove the heat shrink tubing from the power cable leads unless the terminals require replacement. If replacement is required, the connections between the leads and terminals **must be** sealed with heat shrink tubing before applying the silicone adhesive (see **Terminal Housing And Power Cable Reassembly**).

To disconnect the power cable (2) from the terminal housing, pull the terminal plate (22) away from the terminal housing. When shipped from the factory, the connections between the power cable leads and the terminal collars (12 and 24) were encapsulated in heat-shrink tubing (10 and 27) and bonded to the terminal plate with silicone adhesive (not shown). (In service, the adhesive may have been replaced by potting compound during previous repair.) If damage is extensive and the terminal plate and terminals are to be replaced, simply cut the power cable leads above the terminal collars and heat-shrink tubing, and discard the terminal plate and terminals.

If damage is not extensive and it is necessary to replace the terminal plate (22) or terminal components, carefully cut away the tubing and adhesive. Disconnect the power cable leads from the terminal posts, and separate the terminal plate from the terminal housing (8). Unscrew the terminal posts (15 and 17), and remove the terminal collars (12 and 24), posts and terminal plate gasket (23) from the terminal plate.

Remove the hardware (29 and 30) securing the green and yellow ground leads to the terminal housing. Reinstall the hardware.

See **Terminal Housing/Power Cable Reassembly** if no further disassembly is required.

Shaft And Rotor Disassembly

(Figure 1)

See **PUMP END DISASSEMBLY**, and remove all pump end and seal components.

With the pump end disassembled, secure the pump in an inverted position, carefully slide the motor housing (12) off the upper and lower motor housings (13 and 37). Remove the O-ring (15).

Install three 5/8-11 UNC lifting eyes (not supplied) in the tapped holes for the capscrews (8) in the lower motor housing, and hook a three-leg sling to the lifting eyes. Use a suitable hoist to support the pump.

Install two 3/8-16 UNC by 3-inch long capscrews (not supplied) in the jacking holes in the lower motor housing. Use the capscrews to jack the lower motor housing, rotor and shaft assembly (35) bearing cap (7), and both ball bearings (14 and 36) from the upper motor housing as an assembly. If necessary, tap around the parting surfaces with a soft-faced mallet to break the seal between the upper and lower motor housings. Remove the lower motor housing O-ring (10). Remove the jacking screws from the lower motor housing.

Cover the upper motor housing with a clean, lint-free cloth to avoid contamination by dirt or other foreign material.

Set the lower motor housing and rotor assembly on a clean work area. Remove the hardware (38) securing the bearing cap (7) to the lower motor housing, and remove the dyna-seal washers (39).


Steady the rotor and shaft assembly, and separate the lower motor housing. If necessary, tap the impeller end of the rotor shaft with a soft-faced mallet to loosen the seal between the bearing cap and the lower motor housing.

It is not necessary to remove the pipe plug (40) from the lower motor housing. If the optional probe wire and moisture detector are used, remove the hardware securing the probe wire, and unscrew the moisture detector from the motor housing.

If no further disassembly is required, cover the upper motor housing with a clean, lint-free cloth to avoid contamination of the stator by dirt or other foreign materials.

Bearing Removal

(Figure 1)



To prevent damage during removal from the shaft, it is recommended that bearings be cleaned and inspected **in place**. It is **strongly** recommended that the bearings be replaced **any** time the shaft and rotor assembly is removed.

Before removing the bearings from the rotor shaft, clean and inspect the bearings **in place** as follows.

Clean the bearings thoroughly in **fresh** cleaning solvent. Dry the bearings with filtered compressed air and coat with light oil.



Most cleaning solvents are toxic and flammable. Use them only in a well ventilated area; free from excessive heat, sparks, and flame. Read and follow all precautions printed on solvent containers.

Rotate the bearings by hand to check for roughness or binding and inspect the bearing balls. If rotation is rough or the bearing balls discolored, replace the bearings.



These bearings are permanently sealed and require no additional lubrication except a coating of light oil on external surfaces to ease reassembly. External surfaces must be kept free of all dirt and foreign material. Failure to do so could damage the bearings or their mating surfaces.

The bearing tolerances provide a tight press fit onto the shaft and a snug slip fit into the motor housing and bearing bore. Replace the shaft and rotor (as an assembly), the motor housing or intermediate if the proper bearing fit is not achieved.

If replacement is required, use a bearing puller to remove the upper ball bearing from the rotor shaft. Use the bearing cap and capscrews (38) in conjunction with the bearing puller to remove the lower bearing (36) from the shaft. Press the lower bearing out of the bearing cap.

Stator Removal

(Figure 1)

Do not remove the stator (34) unless it is defective (open windings, insulation resistance low, or stator core damaged). If the stator must be removed, remove the terminal housing as indicated in **Terminal Housing And Power Cable Disassembly**.


Position an expandable tool, such as a split disc, approximately 2 inches (51 mm) inside the stator, and expand it tightly and squarely on the I.D. Attach a lifting device to the lifting eye of the tool, and raise the assembly approximately 1 inch (25 mm) off the work surface.

The upper motor housing (13) must be heated with a torch to expand them enough for the stator to be removed. Apply heat evenly to the outside of the motor housing; excessive heat is not required. When the motor housing is sufficiently heated, use a soft-faced mallet to rap alternate edges of the motor housing, and “walk” the stator out. Continue this process until the stator clears the motor housing.



Take care not to damage the stator end turns during removal from the motor housing.

After the stator has been removed, remove the key (11). Wrap it in clean, dry rags or other suitable material until reassembly. The stator **must** be kept clean and dry. When handling the stator, **do not** set it on the end windings; lay it on its side.



Do not attempt to rewind the stator. Winding tolerances and materials are closely controlled by the manufacturer, and any deviation can cause damage or operating problems. Replace the stator, or return it to one of The Gorman-Rupp Authorized Submersible Repair Centers or The Gorman-Rupp factory, if defective.

Hoisting Bail

(Figure 1)

If the hoisting bail (23) requires replacement, remove the hardware (19, 20, 21 and 22) securing the bail to the motor housing. Make sure the bushings (22) are in place when installing the hoisting bail.

MOTOR REASSEMBLY



Do not attempt to rewind the stator. Winding tolerances and materials are closely controlled by the manufacturer, and any deviation can cause damage or operating problems. Replace the stator, or return it to one of The Gorman-Rupp Authorized Submersible Repair Centers or The Gorman-Rupp factory, if defective.

NOTE

Reuse of old O-rings, gaskets, shaft seal parts will result in premature leakage or reduce pump performance. It is strongly recommended that new O-rings and shaft seal assemblies be used during reassembly (see the parts lists for numbers).

Stator Installation

(Figure 1)

NOTE

Stator installation involves heating the upper motor housing and the application of insulating paint to

*the stator O.D. Both processes must be done quickly and at approximately the same time to allow the stator to slide into the motor housing **before the paint dries** or the housing cools. Therefore it is recommended that these steps be performed by two people to promote efficient installation of the stator.*

Clean all gasket and O-ring surfaces, completely removing any old gasket and cement material. Inspect the sealing surfaces for burrs, nicks and pits which could cause a poor seal, and replace defective parts as required.

Apply a light coating of oil to the O-ring (15) and install it on the motor housing (12).

Thoroughly clean the inside of the upper motor housing (13) with fresh solvent. The interior **must** be dry and free of dirt or lint.



Most cleaning solvents are toxic and flammable. Use them only in a well ventilated area; free from excessive heat, sparks, and flame. Read and follow all precautions printed on solvent containers.

NOTE

When assembled at the factory, the stator was painted with insulating paint prior to installation in the motor housing. It may be necessary to use steel wool or a wire brush to remove excess paint from the I.D. of the motor housing before reassembly.

After the motor housing is thoroughly cleaned, position it on a flat surface with the discharge end down. Do not unwrap the stator (34) until the motor housing has been prepared for stator installation. The stator **must** be kept clean and dry. When handling the stator, do not set it on the end windings; lay it on its side and block it from rolling.

Test the new stator as indicated in **Electrical Testing** in **TROUBLESHOOTING**, Section D, to ensure that no damage has occurred during transit or handling.

NOTE

Remove any drops of varnish from the ends of the

stator before installation to ensure proper stack-up height when assembled.

Position an expandable tool, such as a split disc, approximately 2 inches (51 mm) down inside the stator (opposite the lead wire end), and expand it tightly and squarely on the I.D. Attach a lifting device to the lifting eye of the tool, and carefully lift the assembly. Take care not to damage the stator end turns. Slip a sleeve over the stator leads, or tape them together to protect them during installation.

NOTE

Stator installation involves heating the motor housing. This process must be done quickly to allow the stator to slide into the motor housing before the housing cools.

Stator installation involves heating the upper motor housing and the application of insulating paint to the stator O.D. Both processes must be done quickly and at approximately the same time to allow the stator to slide into the motor housing before the paint dries or the housing cools.

Heat the upper motor housing (13) with a torch to expand it enough for the stator (34) to be installed. When heating the motor housing, **make sure** that the stator is clear to avoid a fire hazard, or damage to the windings. Apply heat evenly to the outside of the housings; excessive heat is not required.

While the motor housing is being heated, another person should paint the stator O.D. with insulating paint. With the stator suspended, apply a **very** thin coat of “Glyptol Red Insulating Paint” (G. E. P/N 31201 or Dolph’s ER-41) to the stator O.D. The paint is fast drying, so it must be applied quickly.

When the motor housing is sufficiently heated, position the stator so that the leads are in line with the terminal opening. Install the key (11), and carefully lower the stator into the motor housing until fully seated against the housing shoulder. Be careful not to damage the stator lead insulation during re-assembly. If the stator “cocks” in the motor housing, remove it and try again.

After the stator is fully and squarely seated on the motor housing shoulder, remove the expandable

disc tool. Untape or remove the protective sleeve from the stator leads.

NOTE

Because of the tight shrink fit between the stator and upper motor housing, excess paint will be forced out as the stator is installed. Use soft rags to absorb any paint that accumulates between the stator and the housing, then use paint thinned to thoroughly clean the housing I.D.

Cover the motor housing with a clean, lint-free cloth while the rotor is being assembled.

Bearing Installation

(Figure 1)

Inspect the rotor shaft (35) for damaged threads, scoring in the seal area, and a nicked or damaged keyway. If the bearings were removed, inspect the bearing areas for scoring or galling. Remove nicks and burrs with a fine file or emery cloth. Inspect the rotor area for separated laminations. If the shaft is bent or damaged, or if the laminations are separated, replace the shaft and rotor (a single assembly).



To prevent damage during removal from the shaft, it is recommended that bearings be cleaned and inspected **in place**. It is **strongly** recommended that the bearings be replaced **any** time the shaft and rotor assembly is removed.

The bearings may be heated to ease installation. An induction heater, hot oil bath, electric oven, or hot plate may be used to heat the bearings. Bearings should **never** be heated with a direct flame or directly on a hot plate.

NOTE

*If a hot oil bath is used to heat the bearings, both the oil and the container must be **absolutely** clean. If the oil has been previously used, it must be **thoroughly** filtered.*

Heat the upper bearing (14) to a uniform temperature **no higher than** 250°F (120°C). Slide the bear-

ing onto the shaft until it is fully seated against the shaft shoulder. This should be done quickly, in one continuous motion, to prevent the bearing from cooling and sticking on the shaft.

Clean the bearing cap (7) , and apply 'Loctite Compound No. R/C 609' to the O.D. of the bearing (36) and the I.D. of the bearing cap. Press the bearing into the cap until fully seated.




Use caution when handling hot bearings to prevent burns.

NOTE

Position the bearing cap, so that when installed on the shaft, the bearing will be positioned as indicated in Figure 4.

INSTALLATION OF SKF 5200 AND 5300 SERIES BEARINGS



NOTE:
THIS BEARING IS MANUFACTURED WITH TWO SEALS OR SHIELDS. WHEN INSTALLED ON THE SHAFT, THE MANUFACTURER'S PART NUMBER DESCRIPTION (LOCATED ON SIDE FACE OF BEARING OR BEARING O.D.) MUST BE LOCATED WITH THE TEXT AWAY FROM THE IMPELLER.

Figure 4. Bearing Installation

After the bearings have been installed and allowed to cool, check to ensure that they have not moved out of position in shrinking. If movement has occurred, use a suitable sized sleeve and a press to reposition the bearings. Make certain that they are seated squarely against the shaft shoulders.

pletely removing any old gasket and cement material. Inspect the sealing surfaces for burrs, nicks and pits which could cause a poor seal. Repair or replace as require.

If heating the bearings is not practical, use a suitable sized sleeve and an arbor (or hydraulic) press to install the bearings on the shaft.



Most cleaning solvents are toxic and flammable. Use them only in a well ventilated area free from excessive heat, sparks, and flame. Read and follow all precautions printed on solvent containers.



When installing the bearings onto the shaft, **never** press or hit against the outer race, balls, or ball cage. Press **only** on the inner race.

Position the rotor (35), assembled bearings (14 and 36) and bearing cap (7) on a work surface with the impeller end up, and use blocks to secure it in this position.

Rotor And Lower Motor Housing Reassembly

(Figure 1)

To ease alignment of the bearing cap and lower motor housing, install two long studs, finger-tight only, 180° apart in the bearing cap mounting holes.

Use **fresh** solvent to clean all gasket and O-ring surfaces of the motor housings (13 and 37), com-

Using a three-leg sling and lifting eyes in the lower motor housing flange holes, carefully lower the

housing over the shaft and lower bearing, guiding the studs in the bearing cap through the holes in the motor housing as it is lowered into place.

Apply 'Never-Seez' or equivalent compound to the threads of the capscrews (38). Use two of the capscrews and dyna seal washers (39) to draw the lower motor housing and bearing cap together. Remove the studs temporarily installed in the bearing cap and install the remaining two capscrews and lockwashers; torque the capscrews evenly in a cross-sequence to 20 ft. lbs. (240 in. lbs. or 2,8 m. kg.).

Rotor And Lower Motor Housing Installation

(Figure 1)

Use **fresh** solvent to clean all O-ring surfaces of the motor housing (12), completely removing any old gasket and cement material. Inspect the sealing surfaces for burrs, nicks and pits which could cause a poor seal. Repair or replace as require.



Most cleaning solvents are toxic and flammable. Use them only in a well ventilated area free from excessive heat, sparks, and flame. Read and follow all precautions printed on solvent containers.

Install the O-ring (10) on the lower motor housing. If the optional probe wire and moisture detector are used, apply 'Loctite Pipe Sealant With Teflon No. 592' or equivalent compound to the threads of the detector, and screw it into the tapped hole in the lower motor housing. Secure the probe wire to the moisture detector with the previously removed hardware. Feed the other end of the probe wire down through the groove in the inside of the upper motor housing, between the stator and the motor housing.

Using a three-leg sling and lifting eyes in the lower motor housing flange holes, carefully lower the assembled motor housing and rotor assembly (35) into the upper motor housing (13), guiding the upper bearing (14) into the motor housing bearing

bore. Tap the lower motor housing with a soft faced mallet until it mates tightly with the upper motor housing.

Apply 'Never-Seez' or equivalent compound to the threads of the capscrews (8), and secure the upper and lower motor housings with the hardware (8 and 9). Torque the capscrews evenly in a cross sequence to 60 ft. lbs. (720 in. lbs. or 8,3 m. kg.).

Motor Housing Reassembly

(Figure 1)

Use **fresh** solvent to clean all O-ring surfaces of the motor housing (12), completely removing any old cement material. Inspect the sealing surfaces for burrs, nicks and pits which could cause a poor seal, and repair or replace as required.



Most cleaning solvents are toxic and flammable. Use them only in a well ventilated area; free from excessive heat, sparks, and flame. Read and follow all precautions printed on solvent containers.

Slide the motor housing (12) over the assembled motor until it seats against the O-ring and upper motor housing shoulder. Be careful not to damage the O-ring, and make sure the pipe plugs (5 and 6) are aligned.

Refer to **PUMP END REASSEMBLY**, and reassemble the pump end components.

Terminal Housing And Power Cable Reassembly And Installation

(Figure 2)



The electrical power used to operate this pump is high enough to cause injury or death. Make certain that the control

handle on the control box is in the OFF position and locked out, or that the power supply to the control box has been otherwise cut off and locked out, before attempting to open or service the pump assembly. Tag electrical circuits to prevent accidental startup. Obtain the services of a qualified electrician to make electrical connections.

Clean the exterior of the power cable with warm water and mild detergent. Check for obvious physical damage. Check the cable for continuity and insulation resistance (see **Electrical Testing** in **TROUBLESHOOTING**). Do not attempt repairs except to cut off either end of the cable; **splicing is not recommended**. Reinstall any wire tags or terminals which may have been removed.



Never attempt to alter the length or repair any power cable with a splice. The pump motor and cable must be completely waterproof. Injury or death may result from alterations.

Use oil to lightly lubricate the upper bore of the terminal housing (8), outside of the pump power cable (2), and the bores of terminal gland (1), cable grip (3), gland bushing (6) and terminal washer (7) for ease of assembly. Slide the terminal gland, cable grip, gland bushing, terminal washer and terminal housing onto the power cable (2), allowing approximately 3 ft. (1 m) of cable to extend beyond the terminal housing. Temporarily tape the green and yellow ground wires to the cable.

Sealing Terminal Housing Connections With Silicone Adhesive

(Figure 2)



Do not attempt to operate this pump un-

less the power cable leads are properly sealed in the terminal housing. Moisture entering the terminal housing could cause a short circuit, resulting in pump damage and possible serious injury or death to personnel.

When shipped from the factory, the cable leads and terminal collars (12 and 24) were encapsulated in heat-shrink tubing (10 and 27), and bonded to the terminal plate (22) with silicone adhesive to provide a water-tight seal. If this insulating material has been damaged or removed during maintenance, **it must** be replaced using materials and equipment approved by Gorman-Rupp (see the Parts List Manual for repair kits).

NOTE

*Heat-shrink tubing **must** be used to seal the power and control cable leads to the terminals before bonding the leads to the terminal plate. If silicone adhesive is not available in the field, a commercially available potting kit may be used to bond the connections to the terminal plate. If this alternate sealing method is used, refer to the instructions in **Sealing Terminal Plate Connections With Potting Compound**. Use **only** materials and heating equipment approved by Gorman-Rupp for field repairs.*

Before resealing the power and control cables, remove all the old adhesive material (or potting compound) from the leads, terminal collars, and terminal plate. Inspect all parts for damage, and replace as required.

NOTE

Clean the cable leads and terminal plate in the areas to be sealed with cleaning solvent. Incomplete sealing will occur if the surfaces are dirt, oil or grease coated.

Slide the terminal housing (8) up the power cable (2) and temporarily secure it.

Assemble the terminal posts (15 and 17), dyna seal washers (13, 14, 19 and 20), and the upper terminal collars (12 and 24) to the terminal plate as shown in Figure C-2. Install the upper terminal plate gasket (23).

NOTE

Both the power cable and motor conductor leads

should be tinned prior to reassembly.

Slide a length of heat-shrink tubing (10 and 27) up over each of the power cable leads, then connecting them to the appropriate terminals (12 and 24) as shown in Figure 5. Secure the leads with the set-screws (11 and 25).

NOTE

If the optional probe wire and moisture detector are used, the brown probe wire lead (W1) should be connected to terminal W1. The brown moisture detector ground lead (W2) should be connected to the same terminal end as the yellow ground check lead, and in turn connected to ground inside the terminal housing.

Slide the tubing down each lead until the terminals are covered and the tubing contacts the terminal plate. The tubing **must** extend up the leads far enough to ensure a good seal.

Carefully heat each tube with a commercially available hot air gun capable of producing 750°F (399°C), and shrink the tubes around the cable leads and terminal collars.



Use **only** Dow-Corning 737 Silicone Adhesive (see the Parts List Manual for the part number) or potting compound for sealing terminal housing connections. Use of unapproved sealing products will void the pump warranty.

NOTE

Do not use a mold or reservoir with the silicone adhesive.




Figure 5. Silicone Adhesive Sealing

See Figure 6 and check terminal locations. Apply a 1/4 to 3/8 in. (6,4 to 9,7 mm) thick layer (maximum) of silicone adhesive around each of the terminal posts as shown in Figure 5. Remove any adhesive from gasketed surfaces.



All air pockets, voids or gaps in the silicone sealant must be removed to ensure a water-tight seal in the terminal housing. Otherwise, moisture entering the terminal housing could cause a short circuit, resulting in pump damage and possible serious injury or death to personnel.

Allow the adhesive to cure for at least one hour before securing the terminal housing to the motor housing.




Figure 6. Terminal Housing Wiring Connections

Sealing Terminal Housing Connections With Potting Compound

(Figure 2)

Potting compound and silicone adhesive have the same electrical properties when correctly applied. Silicone adhesive is used at the factory to facilitate production. A commercially available potting kit (Products Research Corp., part number PR-1201-Q Class 1 potting compound, Chemseal potting compound, part number GS3100, or equivalent) may also be used to seal the connections.

Clean and assemble all terminal components as indicated in **Sealing Terminal Plate With Silicone Adhesive**. Use medium grit sandpaper to prepare the surface of the terminal plate in the area where the potting mold will be installed.

NOTE

Clean the cable lead and terminal plate in the areas to be potted with cleaning solvent before potting. Potting compound will not adhere properly to oil or grease coated surfaces.

Trim the potting mold so it is just long enough to cover the terminal collars. Slide the potting mold up over the leads of the power cable and control cable.

Secure each cable lead as described in the previous section. Slide the potting mold down over the terminal collars and onto the terminal plate. Hang the cable in a vertical position with the terminal plate horizontal. The cable leads and terminals should be centered in the potting mold. Use quick-setting cement, such as ‘3-M Weather Seal’ to secure the potting mold to the terminal plate.



Most potting base compounds contain toluene; use adequate ventilation and avoid prolonged breathing of vapors. Most potting accelerators contain lead; avoid ingestion or prolonged contact with the skin. Read and follow all warnings and recommendations accompanying the potting kit.

See the instructions with the potting kit regarding application life and setting and curing time. Mix the base compound and accelerator and fill the mold until the electrical connections are completely insulated. Tamp the potting material to eliminate air bubbles and ensure the material has completely covered the area around the terminal posts.

NOTE

The potting compound must completely cover the

terminal collar and lead connections.

When potting has been completed, leave the terminal plate assembly undisturbed until the potting material has cured. Complete curing usually takes about 24 hours. Curing time can be shortened by using a heat lamp, but be careful not to melt the potting or potting mold, or burn the cable. When the potting material is no longer “tacky” to the touch, it has cured.

Terminal Housing Installation

(Figure 2)

After the terminal plate has been sealed, slide the terminal housing down the cable. Untape the ground leads and secure them to the ground terminals with the hardware (29 and 30). **Be sure** the leads make good contact with the housing.

Pull gently on the cable to remove any excess length from within the terminal housing. The terminal plate should fit loosely against the terminal housing.

Lubricate the upper bore of the terminal housing, and slide the gland washer (7), bushing (6) and cable grip (3) into place. Slide the terminal gland (1) into place and install the nuts (5). Do not fully tighten the nuts at this time.

NOTE

*A **small** amount of gasket adhesive may be used to hold the upper and lower terminal plate gaskets in place to ease assembly.*

Position the lower terminal plate gasket (21) on the terminal plate (22). Refer to Figure 6. Attach the appropriate motor lead (T1, T2, T3, P1 and P2) to each terminal post (15 and 17) using the allen head setscrews (16 and 18).

Position the terminal housing and terminal plate against the upper motor housing. If required, rotate the terminal housing and twist the motor leads to remove excess slack.

(Figure 1)

Secure the terminal housing assembly to the motor housing with the deform locknuts (33); torque the locknuts evenly in a cross sequence to 20 ft. lbs. (240 in. lbs. or 3 m. kg.).

(Figure 2)

Tighten the nuts (5) drawing the terminal gland (1) down into the terminal bore. **Do not** overtighten and damage the terminal gland or hardware.

NOTE

A .12 in. (3,05 mm) gap is required between the terminal gland cap flange and the terminal housing when tighten the nuts.

See **FINAL ASSEMBLY** and **VACUUM TESTING** followed by **LUBRICATION**.

FINAL ASSEMBLY

(Figure 1)

If the discharge flange (25) was removed from the motor housing, replace the discharge flange gasket (24). Apply ‘Anti-Seize’ or equivalent compound on the flange studs (27), and secure the flange with the nuts (28).

If the hoisting bail (23) was removed, install the bail bushings (22) and secure the bail to the motor housing with the hardware (19, 20 and 21).

Connect the discharge hose, and reposition the pump. If rigid piping or long hose is used, reposition the pump, then connect the piping.

VACUUM TESTING

To ensure the water-tight integrity of the pump, it is recommended that the motor and seal cavities be vacuum tested any time the seal(s) and/or motor are serviced.

Drain **all** of the oil from **both** the seal and motor cavities before performing the test. Oil within the cavities will be drawn into the system, resulting in damage to the vacuum pump or manometer.

Use a manometer with a range of 30 to 0 to 30 inches of mercury to perform the test. **Do not** use a vac-

uum gauge. Vacuum gauges are not sensitive enough to detect minor leaks.

It is recommended that a vacuum pump be used to draw the vacuum on the cavities. If a vacuum pump is not available, a compressor/venturi system may be used. If the compressor/venturi cannot draw the higher vacuum level shown in Table C-1, draw the motor cavity vacuum down as far as the system will allow, then draw the seal cavity down so the differential between the two cavities is the same as the differential between the vacuum readings shown in the table.

Install full-closing ball-type shutoff valves with quick-disconnect fittings in the pipe plug holes in both the motor and seal cavities. Test the motor cavity for its full duration first, then use the shutoff valve to maintain the motor cavity vacuum while testing the seal cavity. The motor cavity vacuum **must** be higher than the vacuum in the seal cavity to prevent separation of the seal faces or unseating the stationary seal seat between the seal and motor cavities.

Figure 7 shows a simple schematic for setting up either a vacuum pump or a venturi/compressor test system.




Figure 7. Vacuum Test System

Table E-1 shows the vacuum to be drawn on each cavity, and the duration to maintain each vacuum reading. **Any** change in vacuum reading during

the test indicates a leak which **must** be identified and corrected before putting the pump back into service.

Table E-1. Vacuum Test Data

Pump Model	Motor Cavity Vacuum (In. Hg.)	Duration (Minutes)	Seal Cavity Vacuum (In. Hg.)	Duration (Minutes)
S6D/S6E	30	3	20	3

LUBRICATION

Seal Cavity

Check the oil level in the seal cavity before initial startup, after the first two weeks of operation, and every month thereafter.

is cool. If the oil level plug is removed when the pump is hot, pressure in the seal cavity can cause hot oil to be ejected as the plug is removed.

To check the seal cavity oil, lay the pump on its side and remove the pipe plug (5) and seal cavity plug (6) in the motor housing. Tip the pump and drain off a small amount of oil into a transparent cup. If the oil level is abnormally low, or the color milky or dark, refer to **Draining Oil From Seal Cavity** in this section for instructions and troubleshooting tips. If the oil is clear, apply 'Loctite Pipe Sealant With Te-



Check the oil level only when the pump

flon No. 592.' or equivalent to the threads of the pipe plug, before reinstalling the plug.

To fill the seal cavity, remove the pipe plug (6) and add the recommended grade of submersible pump oil. Apply 'Loctite Pipe Sealant With Teflon No. 592.' or equivalent to the threads of the pipe plug, before reinstalling the plug.

See Table 1 for quantity of lubricant when lubricating a dry (overhauled) pump. See Table 2 for lubricant specifications.

The grade of lubricant used is critical to the operation of this pump. Use premium quality hydraulic oil

as specified in the following table. Oil must be stored in a clean, tightly closed container in a reasonably dry environment.

Table 1. Oil Quantity

Pump Model	Seal Cavity
S6D	3.5 qts. (3,3 liters)
S6E	4.5 qts. (4,3 liters)

Table 2. Pump Oil Specifications

Specifications:	
Type	Premium high viscosity index, anti-wear hydraulic oil
Viscosity (SSU @ 104°F [40°C])	110 to 155
Viscosity (SSU @ 210°F [100°C])	40 to 50
Dielectric	26,000 (volts-min)
Recommended supplier:	
Gulf Oil Company	Gulf Harmony AW Hydraulic Fluid MG 32
Acceptable alternate suppliers:	
Gulf Oil Company	Gulf Harmony 32 AW
Texas Oil Company	Rando HD 32 or HD AZ 32
Sun Oil Company	Sunvis 816 or 916
BP (Also Boron)	Energol-HLP 32
Shell Oil Company	Tellus 32, Tellus T-23 or T32
ARCO	Duro 32
Exxon (Also Esso)	Nuto H 32
Petro-Canada	Harmony HVI 22

Motor Housing Cavity

The motor is cooled by the constant flow of the liquid being discharged thru internal passages sur-

rounding the motor housing, not with oil. The rotor shaft bearings are permanently lubricated, and require no additional lubrication.

**For Warranty Information, Please Visit
www.grpumps.com/warranty
or call:
U.S.: 419-755-1280
Canada: 519-631-2870
International: +1-419-755-1352**

GORMAN-RUPP PUMPS